

AFRL-IF-RS-TR-2007-27
Final Technical Report
January 2007



ARCHITECTURAL VULNERABILITIES OF THIRD- GENERATION PORTABLE DEVICES

Syracuse University

APPROVED FOR PUBLIC RELEASE; DISTRIBUTION UNLIMITED.

STINFO COPY

**AIR FORCE RESEARCH LABORATORY
INFORMATION DIRECTORATE
ROME RESEARCH SITE
ROME, NEW YORK**

NOTICE AND SIGNATURE PAGE

Using Government drawings, specifications, or other data included in this document for any purpose other than Government procurement does not in any way obligate the U.S. Government. The fact that the Government formulated or supplied the drawings, specifications, or other data does not license the holder or any other person or corporation; or convey any rights or permission to manufacture, use, or sell any patented invention that may relate to them.

This report was cleared for public release by the Air Force Research Laboratory Rome Research Site Public Affairs Office and is available to the general public, including foreign nationals. Copies may be obtained from the Defense Technical Information Center (DTIC) (<http://www.dtic.mil>).

AFRL-IF-RS-TR-2007-27 HAS BEEN REVIEWED AND IS APPROVED FOR PUBLICATION IN ACCORDANCE WITH ASSIGNED DISTRIBUTION STATEMENT.

FOR THE DIRECTOR:

/s/

ANDREW J. KARAM
Work Unit Manager

/s/

WARREN H. DEBANY, Jr.
Technical Advisor, Information Grid Division
Information Directorate

This report is published in the interest of scientific and technical information exchange, and its publication does not constitute the Government's approval or disapproval of its ideas or findings.

REPORT DOCUMENTATION PAGE				<i>Form Approved</i> OMB No. 0704-0188	
<small>Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden to Washington Headquarters Service, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188) Washington, DC 20503.</small>					
PLEASE DO NOT RETURN YOUR FORM TO THE ABOVE ADDRESS.					
1. REPORT DATE (DD-MM-YYYY) JAN 2007		2. REPORT TYPE Final		3. DATES COVERED (From - To) Jan 04 – Sep 06	
4. TITLE AND SUBTITLE ARCHITECTURAL VULNERABILITIES OF THIRD-GENERATION PORTABLE DEVICES				5a. CONTRACT NUMBER	
				5b. GRANT NUMBER FA8750-04-2-0058	
				5c. PROGRAM ELEMENT NUMBER 61102F	
6. AUTHOR(S) Shiu-Kai Chin				5d. PROJECT NUMBER 2311	
				5e. TASK NUMBER 00	
				5f. WORK UNIT NUMBER 02	
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) Syracuse University 113 Bowne Hall Syracuse NY 13244-1200				8. PERFORMING ORGANIZATION REPORT NUMBER	
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES) AFRL/IFGB 525 Brooks Rd Rome NY 13441-4505				10. SPONSOR/MONITOR'S ACRONYM(S)	
				11. SPONSORING/MONITORING AGENCY REPORT NUMBER AFRL-IF-RS-TR-2007-27	
12. DISTRIBUTION AVAILABILITY STATEMENT <i>APPROVED FOR PUBLIC RELEASE; DISTRIBUTION UNLIMITED. PA# 07-029</i>					
13. SUPPLEMENTARY NOTES					
14. ABSTRACT The development of the Handheld evidence Recovery Operator (HERO) has created a new paradigm for extracting evidence from portable devices without modifying the device. We developed a handheld evidence recovery operator to address the challenges created by user passwords and PINs, and a standalone tool to copy the data located on the device to an external storage medium without modifying the device.					
15. SUBJECT TERMS Forensic, Vulnerability, VOIP, Cellular Phone					
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT UL	18. NUMBER OF PAGES 77	19a. NAME OF RESPONSIBLE PERSON Andrew J. Karam
a. REPORT U	b. ABSTRACT U	c. THIS PAGE U			19b. TELEPHONE NUMBER (Include area code)

Table of Contents

1. Objectives	1
2. Summary of Work Proposed	1
2.1. Voice Over IP technology.....	1
2.2 Forensic evaluation of personal data assistants.....	1
2.3 Develop algorithms for secure covert communications.....	1
Appendix A – Voice Over IP Providers	9
Appendix B - Source Code for Voice over IP Programs	10
Appendix C – SIP Packet.....	16
Appendix D – Source Code for HERO Acquisition Tool.....	17
Appendix E – PocketPC Processes.....	38
Appendix F – Handheld Evidence Recovery Operator.....	67

List of Figures

Figure 1: Screen Shot of HERO	5
Figure 2: Screen Shot of HERO Acquisition Tool	7

1.0 OBJECTIVES

The objectives of this Cooperative Agreement Award No. FA8750-04-2-0058 and the subsequent ECP covered three distinct activities:

1.1 Investigate the forensic potential of Voice over IP devices and communications.

1.2 Develop techniques and procedures for performing digital forensic analysis on portable digital devices such as pagers and personal data assistants.

2.0 SUMMARY OF WORK PROPOSED

2.1. Investigate the forensic potential of Voice-Over-IP technology

The advent of Internet telephony, commonly known as voice over IP, created new challenges for law enforcement, and hindered them in the task of collecting forensic data and court-admissible evidence. We propose to explore the protocol-inherent features of VoIP in an effort to identify their forensic value, and develop a methodology for obtaining such evidence.

2.2. Forensic evaluation of personal data assistants

The development of the Handheld Evidence Recovery Operator HERO has created a new paradigm for extracting evidence from portable devices without modifying the device. We propose to develop a handheld evidence recovery operator to address the challenges created by user passwords and PINs, and a standalone tool to copy the data located on the device to an external storage medium without modifying the device.

2.3. Develop algorithms for secure covert communications using unstructured broadcast protocols and Peer-to-Peer carriers.

The third task proposes to explore unstructured broadcast protocols to implement covert channels on personal communication systems. The proposed algorithm also exploits Peer-to-Peer carriers to hide the presence of such communication channels.

1. Voice over IP Forensics

A survey of the available VoIP vendors and protocols in the United States was conducted initially. The list of vendors is located in Appendix A. The VoIP forensic study was done using phones from Vonage (<http://www.vonage.com>). The protocol used in this case is SIP for session maintenance and RTP for payload. Both protocols utilize UDP. The payload consists of unencrypted voice traffic. The codec used was the ITU-T g721 standard.

Session Reconstruction: We investigated the possibility of capturing and replaying a VoIP session. A laptop running ethereal, a packet capture program, in promiscuous mode was placed on the same local network as the VoIP phone. The network utilized a hub for demonstration. A switch or router capable of port monitoring can also be used. A filter to capture packets from and to the phone was specified (host 192.168.0.3). In the case where a computer based phone is used, the source and destination ports can be used to restrict the packet capture to the session.

A conversation was initiated from the VoIP phone to another VoIP phone outside the United States and the packets were captured. The same is true for incoming calls and calls placed or received from a regular circuit switched telephone. The captured packets were saved in the pcap library format for further analysis. A tool written in C parses through the capture file to extract packet data in two variations. The first run of the parser extracts all the data in the order it appears in the capture file. This was saved in a file with the extension g721 to denote the codec used. Audio Alchemy MP3 edition was used to convert the data to mp3 format. The mp3 file was played using Microsoft Windows Media Player. The playback was not clear. The second run of the parser extracted the conversation in each direction separately and placed them in separate files. This was done by using the source and destination IP address to determine the direction of flow. These files were converted to mp3. The result in this case was far better than the previous one. The source code for the Packet Parser is located in Appendix B.

An analysis on the effect of dropped packets on the reconstruction was conducted. The preliminary results show that the conversation survives up to about 30% drop in packets. The study was conducted by selecting a percentage of packets randomly and removing them from the capture file before processing. The objective of the effort was to simulate an environment where there is packet loss and to account for out of order delivery. The dropped packets were a percentage of the total number of data packets captured. The source code for the program to drop packets is located in Appendix B.

The SIP packets exchanged during a Voice over IP session contain identifiable information such as the source and destination phone numbers and ip addresses. A recovered SIP packet is located in Appendix C.

We developed a database of next-generation cell phones in commercial use around the world, and we tabulated common characteristics. This database contains information about the processor, memory, operating system, generation, protocols as well as other specifications about the phones. An Excel spreadsheet of this database is attached to this report under separate cover. This spreadsheet is titled "Phone-Specification-Database.xls".

2. HERO Analysis Tool

1. SYSTEM REQUIREMENTS.

- Microsoft Windows XP operating system;
- Intel Pentium or compatible CPU;
- 64 MB of RAM;
- 30 MB free hard disk space;
- Microsoft Visual Studio.net 2003;
- Internet Explorer Version 6.02 or above;

2. COMPONENTS.

- User authentication required for access;
- Actions log kept for all users;
- Ability to select from multiple drives;

- Ability to sort files by known extensions, or user inputted extension;
- Search function;
 - Wildcard search ability
 - Extension search
 - Search entire drive or within specific directories
 - Keeps track of how many items were found in a specific search.
 - Program keeps all files searched for until user clears the results.
- mD5 Hash value calculation;
- View files in text/hex;
- Search for text/hex;
- Limited steganography detection;

3. USING COMPONENTS

3.1 USER AUTHENTICATION / NAME INPUT

- User enters in name, password (which will be hidden), ID number, and CASE ID number.
- User enters in name in order to keep track in the log

3.2 ACTIONS LOG

- The program keeps a detailed log of the user's actions.
- Log kept for:
 - User opens/closes the program
 - User searches for files
 - User aborts searches for files
 - User searches for text/hex in files
 - User views files in hexadecimal or plain text
 - User views the log
- Log contains:
 - User name
 - Date and time action occurred
 - What action occurred (ie. searched for text, searched for a file)
 - Outcome of the action (ie. if the text was found, file found, etc.)
- Log can be viewed by selecting "Log -> View Actions Log".

3.3 CHANGE DRIVE

- Click on the drop down tab under the "Drive Label" and select the drive you wish to access.

3.4 SELECTING FOLDERS

- Double click on the folder that you would like to view the contents of. This is located under the "Directories" label.
- To move up in a directory click on the folder that is located directly above the current folder.

3.5 FILE SORTING

- User can sort files in a given drive by selecting "File -> Type"
- User can sort by known file extensions such as images, html, etc.
- User can input a file extension to sort by.

- Done by selecting "File -> Type -> Other"
- Then inputting the extension desired.

3.6 SELECTING FILES

- Double click on the file you want from the file list box. This is located under the "Files" label.

3.7 VIEWING FILES IN TEXT/HEX

- Double click on the file you want from the file list box. This brings up both the text and hex view of the file.
- To view only the text or the hex, right click on the file then:
 - "View as Plain Text" for the text view.
 - "View in Hexadecimal" for the hex view.

3.8 SEARCH FUNCTION (FILES)

- Search function will only search within specified directories.
- To change search directory select the specific folder you want to search under by double clicking the folder under the "Directories" label.
- To search entire drive select the main folder.
- The search results page will display all the files found, including paths, and how many files were found.
- To clear all search results press the "Clear Results" button, and then "OK".
- Examples of how to search.
 - Search all files on drive by searching for: .
 - Search all files of a specific extension: .extension (example .exe)
 - Search for files that contain specific keywords: keyWord

3.9 SEARCH FUNCTION (TEXT/HEX)

- The user enters the text/hex that they want to search for.
- Select the specific button either "Find Text", or "Find Hex" and the program will search for it inside that specific file.
- If the button is pressed again then the program will search for the next match. The user can continue to find further matches until there are no more.
- After all matches are found, the program will bring the user to the first match found in the program.
- The list box in the lower right hand corner will display a message with the results of your search.

3.10 STEGANOGRAPHY DETECTION

- Right click on a file in the file list box. Left click on: "Hidden Data".

• Viewing Files from the Extraction

To view the files from the extraction, the user needs to select the SD card using "File -> Open". The user can then browse through the extracted folders and files using the browser on the left side of the program. For images the files will open in the right half of the screen. HTML files will open a browser in a separate window with the file, plus it will show the text from the file in the program window. Any type of file can also be viewed in plain text or in hexadecimal. If the

user wants to view files in either of these formats they can right click on the file name and choose which one they prefer. These interpretations of the files will appear in the right half of the program screen.

- **Screening Specific Types of Files**

The user can also screen which types of files will be shown in the file viewer. If they want they can select "File -> Type", and then whichever type of file they want to screen. This will allow them to view a specific group of files that the user is targeting.

- **Summary of Directory**

The user can use this function to receive a summary of the current directory. This will enable them to determine the contents of the directory. If they choose to use this function they need to double click on the folder name, and then right click on it and choose "Get Summary".

3.11 MD5 Hash

- Right Click on the file that you would like to compute the hash for located under the "Files" label.

- Click on "Calculate MD5 Hash"

- The resulting MD5 hash will be displayed under the MD5 Hash text box




Figure 1: Screen Shot of HERO

3. Instructions for HERO Acquisition Tools

HERO has the following functionality:

- Detects the SD card and obtains its name
- Detects if the SD card has been inserted or removed
- Contains four modules
 - *Module 1 – Extracts the ROM
 - *Module 2 – Calculates the size of the object store in RAM and extracts it
 - *Module 3 – Recursively extracts files and folders
 - *Module 4 – Extracts databases
 - *Module 5 – Extracts Registry
- Can function in two modes, Standalone or Autorun
 - *Standalone – each module is self-contained and the user can execute them manually or have them run automatically using the Autorun feature in Windows CE
 - *Autorun – The autorun.exe provided with the package can execute each module in succession, if all modules are required.
- Each module displays a dialog that informs the status of that module. The dialog displays a progress bar indicating the progress. When a module finishes, it displays a message that the process is done and the process automatically closes in 10 seconds without user intervention.

Instructions for Using HERO:

General – Place the zero byte file called exists.hero in the root of the SD card. This file allows the modules to detect the SD card.

Standalone – Place the module(s) in the SD card. Insert the SD card in the target device. Browse to the SD card folder and tap on the executable module to start execution. A dialog with the progress is displayed. Wait until the process is complete and the dialog closes to remove the SD card or execute another module. If the Autorun feature is needed, rename the desired module to autorun.exe, create a folder called 2577 (for target devices with ARM processor) and place the executable in the folder. Insert the card in the device to have the module auto execute.

Autorun – Create a folder called 2577 (for target devices with ARM processor) in the SD card. Place all or some of the following files in the folder: autorun.exe, MODULE1.exe, MODULE2.exe, MODULE3.exe, MODULE4.exe and MODULE5.exe. Insert the card in the target device to have the modules execute. The modules are executed sequentially. Each module displays a dialog with its progress.

Note: Not all Windows CE based Pocket PC devices have the autorun feature enabled. The Autorun is an optional feature and may be disabled by some OEMs.

An analysis of the device before and after HERO executed confirmed that the program did not change the contents of the device. This was shown by performing an MD5 Hash on the device.




Figure 2: Screen Shot of HERO Acquisition Tool

Pocket PC 2003 Emulator:

The following are the steps to install the Pocket PC 2003 SDK, which contains the Pocket PC 2003 Emulator:

Step 1: Download and install Embedded Visual C++ 4.0 from
<http://www.microsoft.com/downloads/details.aspx?familyid=1DACDB3D-50D1-41B2-A107-FA75AE960856&displaylang=en>

Step 2: Download and install the Service Pack 3 for eVC++ 4.0 from
<http://www.microsoft.com/downloads/details.aspx?FamilyID=5bb36f3e-5b3d-419a-9610-2fe53815ae3b&DisplayLang=en>

Step 3: Download and install the Pocket PC 2003 SDK from

<http://www.microsoft.com/downloads/details.aspx?FamilyID=9996b314-0364-4623-9ede-0b5fbb133652&displaylang=en>

The Pocket PC 2003 Emulator can be accessed by navigating through to Start->Programs->Microsoft Pocket PC 2003 SDK->Pocket PC 2003 Emulator

Why Pocket PC 2003 Emulator?

The Pocket PC 2003 Emulator allows local drives/folders to be shared with the Emulator. This facilitates our application by providing a means to browse through the SD card.

How do we use the folder sharing feature?

After starting the emulator, we are provided with the familiar image of a Pocket PC Today screen. To share a folder, select the Folder Sharing option from the File menu on the emulator.

How do we browse the SD card in the emulator?

We use the SD Card Reader for this. Insert the SD card in the card reader. Select the Folder sharing option in the emulator and browse to the drive letter of the SD card. Select the drive and select OK.

Navigate to the My Device on the emulator. The shared folder appears as a storage card. The contents of the SD card can now be accessed through the storage card folder on the emulator.

The source code for all of the HERO Acquisition Modules and Autorun are located in Appendix D.

Appendix E contains a dump file of all of the processes from a PocketPC platform handheld device.

Appendix F contains a paper that includes information about the HERO program and handheld device forensics.

Appendix A - Voice over IP Providers:

VoIP Providers	Web Address
Verizon VoiceWing	http://www22.verizon.com/ForYourHome/VOIP/VOIPHome.aspx
Lingo	http://www.lingo.com/voip/retail/index_retail.jsp
TeleVantage Online (Vertical Communications)	http://www.televantageonline.com/VOIP_Info.htm
NEC Unified Solutions	http://www.necunifiedsolutions.com/cng/
Toshiba and TOTLCOM	http://www.totlcom.com/toshiba_voip.htm
Vonage	http://www.vonage.com/
ShoreTel	http://www.shoretel.com/STCorp/
iConnectHere	http://www.icconnecthere.com/nonmembers/eng/index.asp
Data Network Solutions	http://www.dnetit.com/voip.asp
BroadVoice	http://www.broadvoice.com/?AdCode=google
Net2Phone	http://www.universtelecoms.com/indexuk.htm
AT&T	http://www.att.com/voip/
Skype	http://www.skype.com
3Com	http://www.3com.com/voip/
Yak Worldcity VoIP	http://worldcity.yak.com/en/
SureVoice	http://www.surevoice.com/
ANEW Broadband	http://www.anewbroadband.com/
JustCom	http://www.justcom.biz/file.php/home
Telco Systems	http://www.telco.com/products/Access/EtoOconverters/EdgeLinkT1_Access/

VoIP Hardware Providers	Web Address
RADirect	http://www.rad-direct.com/Prod-VoIP-Hardware-Sphere.htm
VoIP Hardware Center	http://www.voip-news.com/hw/center.htm
VoIP Hardware and Equipment	http://www.callback4u.com/voice-over-ip/hardware.htm

Appendix B Source Code for Voice over IP programs

B.1 - Source Code for Packet Parser:

//This file has the main capture routines. It has been modified from a sample program that demonstrates using the winpcap library

```
#include "main.h"
#include <windows.h>

/* prototype of the packet handler */
//void packet_handler(u_char *param, const struct pcap_pkthdr *header, const
u_char *pkt_data);

//Packet Handler for handling packets in a file

void CaptureFile_handler(u_char *param, const struct pcap_pkthdr *header,
const u_char *pkt_data)
{
    ip_header *ih;
    udp_header *uh;
    char* tdata;
    u_int ip_len;
    FILE* temp;
    u_int tlen;
    int tempVar1 = 0;
    char tempFile1[256];

    /* retireve the position of the ip header */
    ih = (ip_header *) (pkt_data +
        14); //length of ethernet header

    //get length of ip header
    ip_len = (ih->ver_ihl & 0xf) * 4;

    //retireve the position of the tcp header
    uh = (udp_header *) ((u_char*)ih + ip_len);

    //get length of udp header
    tlen = sizeof(udp_header);

    //get the position where data begins
    tdata = (char*)uh + tlen + 12;

    //calculate the total header length
    //hlen = 14+ip_len+tlen+8;

    //int i = 0;
    strcpy(tempFile1, (const char*)param);

    temp = fopen((const char*)tempFile1, "a+");

    fprintf(temp, "%s", tdata);

    fclose(temp);

    return;
```

```

}

int main(int argc, char* argv[])
{
    pcap_t *fp = NULL;
    char tempFile1[256];
    char errbuf[PCAP_ERRBUF_SIZE];

    GetCurrentDirectory(256, tempFile1);

    if ( (fp = pcap_open_offline(argv[1], errbuf) ) == NULL)
    {
        return 0;
    }

    pcap_loop(fp, 0, CaptureFile_handler, (u_char*)argv[2]);

    return 1;
}

```

B.2 - Source Code for Program to Drop Packets:

```

//This file has the main capture routines. It has been modified from a sample
program that demonstrates using the winpcap library
#include <vector>
#include <algorithm>
#include "rand.h"
#include "main.h"

//#include <windows.h>

/* prototype of the packet handler */
//void packet_handler(u_char *param, const struct pcap_pkthdr *header, const
u_char *pkt_data);

//Packet Handler for handling packets in a file

int NumPackets = 0;
int TotPackets = 0;
int PacketCount = 0;
std::vector<int> DropPackets;
std::vector<int>::iterator temp;

void CaptureFile_handler(u_char *param, const struct pcap_pkthdr *header,
const u_char *pkt_data)
{
    PacketCount++;
    if(temp != DropPackets.end())
    {
        //printf("%d\n", PacketCount);
        if(*temp == PacketCount)
        {
            //printf("%d\n", PacketCount);

```

```

        temp++;
        return;
    }
}

ip_header *ih;
udp_header *uh;
char* tdata;
u_int ip_len;
FILE* temp;
u_int tlen;
int tempVar1 = 0;
char tempFile1[256];

/* retireve the position of the ip header */
ih = (ip_header *) (pkt_data +
    14); //length of ethernet header

//get length of ip header
ip_len = (ih->ver_ihl & 0xf) * 4;

//retireve the position of the tcp header
uh = (udp_header *) ((u_char*)ih + ip_len);

//get length of udp header
tlen = sizeof(udp_header);

//get the position where data begins
tdata = (char*)uh + tlen + 12;

//calculate the total header length
//hlen = 14+ip_len+tlen+8;

//int i = 0;
strcpy(tempFile1, (const char*)param);

temp = fopen((const char*)tempFile1, "a+");

fprintf(temp, "%s", tdata);

fclose(temp);

return;
}

void CountPackets_handler(u_char *param, const struct pcap_pkthdr *header,
const u_char *pkt_data)
{
    TotPackets++;
    return;
}

void q_sort(int left, int right)
{
    int pivot;
    int l_hold;

```



```

int r_hold;

l_hold = left;
r_hold = right;
pivot = DropPackets.at(left);
while (left < right)
{
    while ((DropPackets.at(right) >= pivot) && (left < right))
        right--;
    if (left != right)
    {
        DropPackets.at(left) = DropPackets.at(right);
        left++;
    }
    while ((DropPackets.at(left) <= pivot) && (left < right))
        left++;
    if (left != right)
    {
        DropPackets.at(right) = DropPackets.at(left);
        right--;
    }
}
DropPackets.at(left) = pivot;
pivot = left;
left = l_hold;
right = r_hold;
if (left < pivot)
    q_sort(left, pivot-1);
if (right > pivot)
    q_sort(pivot+1, right);
}

void quickSort(int array_size)
{
    q_sort(0, array_size-1);
}

int main(int argc, char* argv[])
{
    long int RandomVal = 0;
    int TheCount = 0;
    int TheCount1 = 0;
    pcap_t *fp = NULL;
    char tempFile1[256];
    char errbuf[PCAP_ERRBUF_SIZE];

    GetCurrentDirectory(256, tempFile1);

    if ( (fp = pcap_open_offline(argv[1], errbuf) ) == NULL)
    {
        printf("Could Not Open File %s\n", argv[1]);
        return 0;
    }

    pcap_loop(fp, 0, CountPackets_handler, (u_char*)argv[0]);

    NumPackets = atoi(argv[3]);

```

```

//printf("\nTotal Packets: %d\nPackets to Drop: %d\n", TotPackets,
NumPackets);
    if(NumPackets == 101)
    {
    }

    else
    {

        NumPackets = (NumPackets*TotPackets)/100;

        TheCount = NumPackets;
        //TheCount1 = NumPackets;

        printf("%d\n%d\n", NumPackets, TheCount);

        randctx tempRand;

        randinit(&tempRand, FALSE);

        while(NumPackets)
        {

            RandomVal = rand(&tempRand);
            if(RandomVal >= 1)
            {
                while(RandomVal >= TotPackets)
                {
                    RandomVal = RandomVal - (TotPackets-1);
                }
            }
            else
            {
                while(RandomVal < 1)
                {
                    RandomVal = RandomVal + (TotPackets-1);
                }
            }
            //printf("%d\n", RandomVal);

            std::vector<int>::iterator temp1;

            temp1 = find(DropPackets.begin(), DropPackets.end(), RandomVal);
            if(temp1 == DropPackets.end())
            {
                DropPackets.push_back(RandomVal);
                NumPackets--;
                TheCount1++;
            }
        }

        //quickSort(TheCount1);
        sort(DropPackets.begin(), DropPackets.end());

        printf("Total Packets: %d\nPackets to Drop: %d", TotPackets,
TheCount1);
    }

```

```

        //for(temp = DropPackets.begin();temp != DropPackets.end(); temp++)
            //printf("%d\n", *temp);
temp = DropPackets.begin();

if ( (fp = pcap_open_offline(argv[1], errbuf) ) == NULL)
{
    printf("Could Not Open File %s\n", argv[1]);
    return 0;
}

printf("%d\n%d\n", NumPackets, TheCount);

pcap_loop(fp, 0, CaptureFile_handler, (u_char*)argv[2]);

return 1;
}

```

Appendix C – SIP Packet

The SIP packets exchanged by the end points reveal the source and destination phone number, ip address and caller id. The gateway used for packet forwarding is also available in the packet.

The following SIP packet payload shows the caller ID, phone number and IP address of the destination in bold.

```
ACK sip:13157039646@216.115.25.19:5061 SIP/2.0
From: "315-299-
2459"<sip:13152992459@atlas5.atlas.vonage.net:5061;user=phone>;tag=c0a80003-13c5-
42453181-238ec570-7fbd
To: "rukmanis"<sip:13157039646@atlas5.atlas.vonage.net:5061;user=phone>;tag=594026082
Call-ID: 9451d2ec-20106-1111830913-35793553-128603419702118500000000-0@192.168.0.3
CSeq: 2 ACK
Via: SIP/2.0/UDP 192.168.0.3:5061;branch=z9hG4b K-42453184-238ecf98-5ab9
Max-Forwards: 70
Contact: <sip:13152992459@192.168.0.3:5061;transport=UDP;user=phone>
Route: <sip:13157039646@216.115.27.29:5060>
Route: <sip:13157039646@216.115.25.198:5061>
Route: <sip:13157039646@196.12.47.41:43780>
Proxy-Authorization: Digest username="13152992459", realm="216.115.25.19",
nonce="1685999676", uri="sip:13157039646@atlas5.atlas.vonage.net:5061;user=phone",
response="15860f8a91a2c19c6589d2ccf7df7bcb", algorithm=MD5
Content-Length: 0
```

Appendix D - Source Code for HERO Acquisition Tool

D.1 – Source code for Autorun

```
#include <windows.h>

BOOL DirNavigate(LPTSTR searchPath)
{

    HANDLE fileHandle;
    WIN32_FIND_DATA findData;

    //TCHAR searchPath[MAX_PATH];
    TCHAR ThePath[MAX_PATH];

    lstrcpy (searchPath, TEXT("\\*..*"));

    fileHandle = FindFirstFile (searchPath, &findData);

    if (fileHandle != INVALID_HANDLE_VALUE)
    {
        do
        {

            lstrcpy(searchPath, TEXT("\\"));

            lstrcat(searchPath, findData.cFileName);

            //MessageBox(NULL, searchPath, TEXT("Search"), MB_OK);

            if (findData.dwFileAttributes & FILE_ATTRIBUTE_DIRECTORY)
            {
                //if (findData.dwFileAttributes &
                FILE_ATTRIBUTE_TEMPORARY)
                //{

                    lstrcpy(ThePath, TEXT("\\"));
                    lstrcat(ThePath, findData.cFileName);
                    lstrcat(ThePath, TEXT("\\exists.hero"));
                    //MessageBox(NULL, ThePath, TEXT("Search"),
                    MB_OK);

                    HANDLE temp = CreateFile(ThePath, GENERIC_READ,
                    0, NULL, OPEN_EXISTING, FILE_ATTRIBUTE_NORMAL, NULL);
                    if (temp != INVALID_HANDLE_VALUE)
                    {
                        CloseHandle(temp);
                        FindClose (fileHandle);
                        //MessageBox(NULL, searchPath,
                        TEXT("SD"), MB_OK);

                        return TRUE;
                    }
                //}
            }
        } while (FindNextFile(fileHandle, &findData));
    }
}
```

```

        }

    }
    while (FindNextFile (fileHandle, &findData));

}
FindClose (fileHandle);

return FALSE;

}

int WINAPI WinMain (HINSTANCE hInstance, HINSTANCE hPrevInstance,
                    LPWSTR lpCmdLine, int nCmdShow)
{

    if(lstrcmp(lpCmdLine, TEXT("uninstall")) == 0) return 0;

    if((lstrcmp(lpCmdLine, TEXT("install")) == 0) || (lstrcmp(lpCmdLine,
TEXT("")) == 0))
    {
        TCHAR SDPath[MAX_PATH];
        if(DirNavigate(SDPath) == FALSE)
            return 0;
        //MessageBox(NULL, SDPath, TEXT("Hi"), MB_OK);

PROCESS_INFORMATION pi;
int rc = 0;

TCHAR ExePath[MAX_PATH];

lstrcpy(ExePath, SDPath);
lstrcat(ExePath, _T("\\2577\\MODULE1.exe"));

rc = CreateProcess (ExePath, SDPath, NULL, NULL, FALSE,
                    0, NULL, NULL, NULL, &pi);
WaitForSingleObject(pi.hProcess, INFINITE);
if (rc) {
    CloseHandle (pi.hThread);
    CloseHandle (pi.hProcess);
}

rc = 0;

lstrcpy(ExePath, SDPath);
lstrcat(ExePath, _T("\\2577\\MODULE2.exe"));

rc = CreateProcess (ExePath, SDPath, NULL, NULL, FALSE,
                    0, NULL, NULL, NULL, &pi);
WaitForSingleObject(pi.hProcess, INFINITE);
if (rc) {
    CloseHandle (pi.hThread);
    CloseHandle (pi.hProcess);
}
}

```

```

rc = 0;

lstrcpy(ExePath, SDPath);
lstrcat(ExePath, _T("\\2577\\MODULE3.exe"));

rc = CreateProcess (ExePath, SDPath, NULL, NULL, FALSE,
                    0, NULL, NULL, NULL, &pi);
WaitForSingleObject(pi.hProcess, INFINITE);
if (rc) {
    CloseHandle (pi.hThread);
    CloseHandle (pi.hProcess);
}

rc = 0;

lstrcpy(ExePath, SDPath);
lstrcat(ExePath, _T("\\2577\\MODULE4.exe"));

rc = CreateProcess (ExePath, SDPath, NULL, NULL, FALSE,
                    0, NULL, NULL, NULL, &pi);
WaitForSingleObject(pi.hProcess, INFINITE);
if (rc) {
    CloseHandle (pi.hThread);
    CloseHandle (pi.hProcess);
}

rc = 0;

/*rc = CreateProcess (TEXT ("\\Storage Card\\MODULE5.exe"), SDPath, NULL,
NULL, FALSE,
                    0, NULL, NULL, NULL, &pi);
WaitForSingleObject(pi.hProcess, INFINITE);
if (rc) {
    CloseHandle (pi.hThread);
    CloseHandle (pi.hProcess);
}*/
}
return 1;
}

```

D.2 – Source code for Module 1

```

#include "stdafx.h"
#include "main.h"
#include "Dlg.h"
#include <windows.h>
#include "pkfuncs.h"

////////////////////////////////////
// CFileApp

BEGIN_MESSAGE_MAP(CFileApp, CWinApp)

```

```

END_MESSAGE_MAP()

////////////////////////////////////
// CFileApp construction

CFileApp::CFileApp()
    : CWinApp()
{
    pDlg = NULL;
}

CFileApp::~CFileApp()
{
    delete pDlg;
}

CFileApp theApp;

BOOL CFileApp::InitInstance()
{
    TCHAR temp[MAX_PATH];
    //HINSTANCE SDdl1;
    //LPFNDLLFUNC1 SDadrs;

    if ((lstrcmp(m_lpCmdLine, TEXT("")) == 0) || (lstrcmp(m_lpCmdLine,
TEXT("install")) == 0) || (lstrcmp(m_lpCmdLine, TEXT("uninstall")) == 0))
    {
        //lstrcpy(temp, _T("\\Storage Card"));
        return FALSE;
    }

    //else
    //{
        lstrcpy(temp, m_lpCmdLine);
    //}

    int myProgressPos;

    pDlg = new CFileDlg();

    pDlg->m_bFullScreen = FALSE;
    int iResponse = pDlg->Create(IDD_FILE_DIALOG, NULL);

    //Sleep(2000);

    pDlg->SetDlgItemText(IDC_EDIT1, _T("Extracting ROM..."));

    //lstrcpy(temp, m_lpCmdLine);

    if(!ROMReader(pDlg, temp))

```



```

    {
        Sleep(2000);
        delete this;
        return FALSE;
    }

    myProgressPos = pDlg->myPctrl.GetPos();
    if (myProgressPos < 10)
    {
        for(int tInker = myProgressPos; tInker < 10; tInker++)
        {
            pDlg->myPctrl.StepIt();
            Sleep(5);
        }
    }

    pDlg->SetDlgItemText(IDC_EDIT1, _T("Extracting ROM...Done"));

    Sleep(2000);

    delete this;

    // Since the dialog has been closed, return FALSE so that we exit the
    // application, rather than start the application's message pump.
    return FALSE;
}

int CFileApp::ROMReader(CFileDialog* pDlg, TCHAR SDPath[MAX_PATH])
{
    lstrcat(SDPath, TEXT("\\Rom"));

    BOOL temp = CreateDirectory(SDPath, NULL);

    lstrcat(SDPath, _T("\\Rom.bin"));

    if(!temp)
    {
        FILE* existFile;
        existFile = _wfopen(SDPath, _T("r"));
        if (existFile != NULL)
        {
            fclose(existFile);
            pDlg->SetDlgItemText(IDC_EDIT1, _T("ROM image exists"));
            return 0;
        }
    }

    //lstrcat(SDPath, TEXT("\\RomImage.bin"));

    DWORD objStoreLoc = 0x80000000;

    SetProcPermissions(0xFFFF);
    #define SIZE (1024 * 1024 * 4)

```

```

    BYTE* lpv;
    BOOL bRet = TRUE;
    int Offset = 0;

    FILE* output;

    while ((objStoreLoc+Offset) < 0x82000000)
    {
        lpv = (BYTE*) VirtualAlloc(0, SIZE, MEM_RESERVE, PAGE_NOACCESS);

        bRet = VirtualCopy(lpv, (void*)(objStoreLoc+Offset), SIZE,
PAGE_READWRITE | PAGE_NOCACHE);

        if (bRet)
        {
            output = _wfopen(SDPath, _T("a+b"));
            fwrite(lpv, sizeof(BYTE), SIZE, output);
            fclose(output);
        }

        VirtualFree(lpv, 0, MEM_RELEASE);

        Offset = Offset + SIZE;
        pDlg->myPctrl.StepIt();
    }

    return 1;
}

```

D.3 – Source code for Module 2

```

#include "stdafx.h"
#include "main.h"
#include "Dlg.h"
#include <windows.h>
#include "pkfuncs.h"

////////////////////////////////////
// CFileApp

BEGIN_MESSAGE_MAP(CFileApp, CWinApp)

END_MESSAGE_MAP()

////////////////////////////////////
// CFileApp construction

CFileApp::CFileApp()
: CWinApp()
{
    pDlg = NULL;
}

```

```

CFileApp::~CFileApp()
{
    delete pDlg;
}

CFileApp theApp;

BOOL CFileApp::InitInstance()
{
    //if(lstrcmp(m_lpCmdLine, TEXT("uninstall")) == 0) return 0;

    //if(lstrcmp(m_lpCmdLine, TEXT("install")) == 0)
    //{

        TCHAR temp[MAX_PATH];

        if ((lstrcmp(m_lpCmdLine, TEXT("")) == 0) || (lstrcmp(m_lpCmdLine,
TEXT("install")) == 0) || (lstrcmp(m_lpCmdLine, TEXT("uninstall")) == 0))
        {
            //lstrcpy(temp, _T("\\Storage Card"));
            return FALSE;
        }

        //else
        //{
            lstrcpy(temp, m_lpCmdLine);
        //}

        int myProgressPos;

        pDlg = new CFileDlg();

        pDlg->m_bFullScreen = FALSE;
        int iResponse = pDlg->Create(IDD_FILE_DIALOG, NULL);

        pDlg->SetDlgItemText(IDC_EDIT1, _T("Extracting Object Store..."));

        if(!ObjReader(pDlg, temp))
        {
            Sleep(2000);
            delete this;
            return FALSE;
        }

        myProgressPos = pDlg->myPctrl.GetPos();
        if (myProgressPos < 10)
        {
            for(int tInker = myProgressPos; tInker < 10; tInker++)

```

```

        {
            pDlg->myPctrl.StepIt();
            Sleep(5);
        }
    }

    pDlg->SetDlgItemText(IDC_EDIT1, _T("Extracting Object Store...Done"));

    Sleep(2000);

    delete this;

    //}

    // Since the dialog has been closed, return FALSE so that we exit the
    // application, rather than start the application's message pump.
    return FALSE;
}

int CFileApp::ObjReader(CFileDlg* pDlg, TCHAR SDPath[MAX_PATH])
{
    lstrcat(SDPath, _T("\\ObjStore"));

    BOOL SDDir = CreateDirectory(SDPath, NULL);

    lstrcat(SDPath, _T("\\ObjStore.bin"));

    if(!SDDir)
    {
        FILE* existFile;
        existFile = _wopen(SDPath, _T("r"));
        if (existFile != NULL)
        {
            fclose(existFile);
            pDlg->SetDlgItemText(IDC_EDIT1, _T("Object Store image
exists"));
            return 0;
        }
    }

    DWORD objStoreLoc = GetFSHeapInfo();

    SetProcPermissions(0xFFFF);
    #define SIZE (1024*1024*4)

    BYTE* lpv;
    BOOL bRet = TRUE;
    int Offset = 0;

    STORE_INFORMATION StoreInfoVar;
    FILE* output;
    GetStoreInformation(&StoreInfoVar);

```

```

        DWORD temp = objStoreLoc + StoreInfoVar.dwStoreSize;

        while ((objStoreLoc+Offset) < temp)
        {
            lpv = (BYTE*) VirtualAlloc(0, SIZE, MEM_RESERVE, PAGE_NOACCESS);

            if(!VirtualCopy(lpv, (void*)(objStoreLoc+Offset), SIZE,
PAGE_READWRITE | PAGE_NOCACHE))
            {
                VirtualFree(lpv, 0, MEM_RELEASE);
                return 1;
            }

            output = _wfopen(SDPath, _T("a+b"));
            fwrite(lpv, sizeof(BYTE), SIZE, output);
            fclose(output);

            VirtualFree(lpv, 0, MEM_RELEASE);

            Offset = Offset + SIZE;

            pDlg->myPctrl.StepIt();

        }

        return 1;
    }
}

```

D.4 – Source code for Module 3

```

#include "stdafx.h"
#include "main.h"
#include "Dlg.h"
#include <windows.h>
// #include "md5.h"

// ////////////////////////////////////////
// CFileApp

BEGIN_MESSAGE_MAP(CFileApp, CWinApp)

END_MESSAGE_MAP()

// ////////////////////////////////////////
// CFileApp construction

CFileApp::CFileApp()
    : CWinApp()
{
    pDlg = NULL;
}

CFileApp::~CFileApp()

```

```

{
    delete pDlg;
}

CFileApp theApp;

BOOL CFileApp::InitInstance()
{
    if ((lstrcmp(m_lpCmdLine, TEXT("")) == 0) || (lstrcmp(m_lpCmdLine,
TEXT("install")) == 0) || (lstrcmp(m_lpCmdLine, TEXT("uninstall")) == 0))
    {
        //lstrcpy(temp, _T("\\Storage Card"));
        return FALSE;
    }

    TCHAR temp[MAX_PATH];

    //else
    //{
        lstrcpy(temp, m_lpCmdLine);
    //}

    int myProgressPos;

    pDlg = new CFileDialog();

    pDlg->m_bFullScreen = FALSE;
    int iResponse = pDlg->Create(IDD_FILE_DIALOG, NULL);

    //lstrcpy(temp, _T("\\Storage Card"));
    lstrcat(temp, _T("\\Files"));

    BOOL SDDir = CreateDirectory(temp, NULL);

    if(!SDDir)
    {
        pDlg->SetDlgItemText(IDC_EDIT1, _T("Files folder exists"));
        Sleep(2000);
        delete this;
        return FALSE;
    }

    SYSTEMTIME TheTime;
    GetSystemTime(&TheTime);
    FILE* timeFile;
    timeFile = fopen("\\Storage Card\\SystemTime.txt", "a+");
    fprintf(timeFile, "%04d-%02d-%02d %02d:%02d:%02d.%03d\\t\\t",

```

```

        TheTime.wYear, TheTime.wMonth, TheTime.wDay,
        TheTime.wHour, TheTime.wMinute,
TheTime.wSecond, TheTime.wMilliseconds);
    fclose(timeFile);

    Sleep(2000);

    pDlg->SetDlgItemText(IDC_EDIT1, _T("Extracting Files..."));

    TheFunction(pDlg, temp);

    myProgressPos = pDlg->myPctrl.GetPos();
    if (myProgressPos < 400)
    {
        for(int tInker = myProgressPos; tInker < 400; tInker++)
        {
            pDlg->myPctrl.StepIt();
            Sleep(5);
        }
    }

    pDlg->SetDlgItemText(IDC_EDIT1, _T("Extracting Files...Done"));

    Sleep(2000);

    delete this;

    // Since the dialog has been closed, return FALSE so that we exit the
    // application, rather than start the application's message pump.
    return FALSE;
}

int CFileApp::TheFunction(CFileDialog* pDlg, TCHAR szName[MAX_PATH])
{
    //TCHAR szName[MAX_PATH];

    int j = 0;

    //lstrcpy(szName, TEXT("\\Storage Card\\Files"));

    FILE *Logfile;

    Logfile = fopen("\\Storage Card\\Log.txt", "a+");

    fprintf(Logfile, "File Name\t\tDirectory\t\tCreation Time\t\tLast
Access Time\t\tLast Write Time\n\n");

    if (DirNavigate(TEXT("\\"), szName, 0, pDlg, Logfile))
    {
        /*lstrcat(szName, TEXT("\\Windows"));
        CreateDirectory(szName, NULL);
        if (DirNavigate(TEXT("\\Windows\\"), szName, 1, pDlg, Logfile))

```

```

        {
            }*/
    }
    fclose(Logfile);

    return 1;
}

bool CFileApp::DirNavigate(TCHAR dirName[MAX_PATH], TCHAR
storedirName[MAX_PATH], int i, CFileDialog* pDlg, HANDLE Logfile)
{

    HANDLE fileHandle;
    WIN32_FIND_DATA findData;

    TCHAR searchPath[MAX_PATH];

    lstrcpy (searchPath, dirName);
    lstrcat (searchPath, TEXT("*.*)");

    // TEST CODE

    //MessageBox(NULL, searchPath, TEXT("hello"), MB_OK);

    //lstrcpy (searchPath, storedirName);

    //MessageBox(NULL, dirName, TEXT("Hello"), MB_OK);

    //END TEST CODE

    fileHandle = FindFirstFile (searchPath, &findData);

    if (fileHandle != INVALID_HANDLE_VALUE)
    {
        do
        {

            lstrcpy(searchPath, dirName);

            lstrcat(searchPath, findData.cFileName);

            //TEST CODE

            //MessageBox(NULL, searchPath, TEXT("Source"), MB_OK);

            //END TEST CODE

            TCHAR destPath[MAX_PATH];

            lstrcpy(destPath, storedirName);
            lstrcat(destPath, TEXT("\\"));
            lstrcat(destPath, findData.cFileName);

```



```

//TEST CODE

//MessageBox(NULL, destPath, TEXT("Dest"), MB_OK);

//END TEST CODE

if (findData.dwFileAttributes & FILE_ATTRIBUTE_DIRECTORY)
{
    if (lstrcmp(searchPath, TEXT("\\Storage Card")) != 0)
    {
        //if (lstrcmp(searchPath, TEXT("\\Windows")) !=
0)
        //{
            CreateDirectory(destPath, NULL);
            lstrcat(searchPath, TEXT("\\"));
            DirNavigate(searchPath, destPath, i,
pDlg, Logfile);
        //}
        /*if (i == 1)
        {
            CreateDirectory(destPath, NULL);
            lstrcat(searchPath, TEXT("\\"));
            DirNavigate(searchPath, destPath, i,
pDlg, Logfile);
        }*/
    }
}
if (!(findData.dwFileAttributes &
FILE_ATTRIBUTE_DIRECTORY))
{
    //pDlg->SetDlgItemText(IDC_EDIT1, findData.cFileName);

    //CopyFile(searchPath, destPath, 0);

    //if (i == 1)
    //{
        pDlg->SetDlgItemText(IDC_EDIT1, findData.cFileName);
        CopyFile(searchPath, destPath, 0);
    //}

    //if (lstrcmp(searchPath, TEXT("\\Windows")) != 0)
    //{
        //pDlg->SetDlgItemText(IDC_EDIT1, findData.cFileName);
        //CopyFile(searchPath, destPath, 0);
    //}

    fprintf(Logfile, "%ls\t%ls\t", findData.cFileName,
searchPath);

    SYSTEMTIME systime;
    FileTimeToSystemTime(&findData.ftCreationTime,
&systime);

    fprintf(Logfile, "%04d-%02d-%02d
%02d:%02d:%02d.%03d\t",
systime.wYear, systime.wMonth, systime.wDay,

```

```

                                systime.wHour, systime.wMinute,
systime.wSecond,systime.wMilliseconds);
                                FileTimeToSystemTime(&findData.ftLastAccessTime,
&systime);
                                fprintf(Logfile, "%04d-%02d-%02d
%02d:%02d:%02d.%03d\t",
                                systime.wYear, systime.wMonth, systime.wDay,
                                systime.wHour, systime.wMinute,
systime.wSecond,systime.wMilliseconds);
                                FileTimeToSystemTime(&findData.ftLastWriteTime,
&systime);
                                fprintf(Logfile, "%04d-%02d-%02d
%02d:%02d:%02d.%03d\n",
                                systime.wYear, systime.wMonth, systime.wDay,
                                systime.wHour, systime.wMinute,
systime.wSecond,systime.wMilliseconds);

                                }
                                }
                                while (FindNextFile (fileHandle, &findData));

                                }
                                FindClose (fileHandle);
                                pDlg->myPctrl.StepIt();

                                return 1;

                                }

```

D.5 – Source code for Module 4

```

#include "stdafx.h"
#include "main.h"
#include "Dlg.h"
#include <windows.h>

////////////////////////////////////
// CFileApp

BEGIN_MESSAGE_MAP(CFileApp, CWinApp)

END_MESSAGE_MAP()

////////////////////////////////////
// CFileApp construction

CFileApp::CFileApp()
: CWinApp()
{
    pDlg = NULL;
}

CFileApp::~~CFileApp()

```

```

{
    delete pDlg;
}

CFileApp theApp;

BOOL CFileApp::InitInstance()
{
    TCHAR temp[MAX_PATH];

    if ((lstrcmp(m_lpCmdLine, TEXT("")) == 0) ||
        (lstrcmp(m_lpCmdLine, TEXT("install")) == 0) || (lstrcmp(m_lpCmdLine,
TEXT("uninstall")) == 0))
    {
        //lstrcpy(temp, _T("\\Storage Card"));
        return FALSE;
    }

    //else
    //{
        lstrcpy(temp, m_lpCmdLine);
    //}

    int myProgressPos;

    pDlg = new CFileDialog();

    pDlg->m_bFullScreen = FALSE;

    int iResponse = pDlg->Create(IDD_FILE_DIALOG, NULL);

    //pDlg->SetDlgItemText(IDC_EDIT1, _T("To the HERO-Mobile..."));

    lstrcat(temp, _T("\\Database"));

    BOOL SDDir = CreateDirectory(temp, NULL);

    pDlg->SetDlgItemText(IDC_EDIT1, _T("Extracting Databases..."));

    Sleep(1000);

    if (!SDDir)
    {
        pDlg->SetDlgItemText(IDC_EDIT1, _T("Database folder exists"));
        Sleep(2000);
        delete this;
        return FALSE;
    }

    lstrcat(temp, _T("\\Databases.cdb"));

```

```

DBFunction(pDlg, temp);

myProgressPos = pDlg->myPctrl.GetPos();
if (myProgressPos < 100)
{
    for(int tInker = myProgressPos; tInker < 100; tInker++)
    {
        pDlg->myPctrl.StepIt();
        Sleep(5);
    }
}

pDlg->SetDlgItemText(IDC_EDIT1, _T("Extracting Databases...Done"));

Sleep(2000);

delete this;

//}

// Since the dialog has been closed, return FALSE so that we exit the
// application, rather than start the application's message pump.
return FALSE;
}

void DumpDatabaseByName(HANDLE h, HANDLE destDBhandle)
{

    CEOID dbid=0;

    CEPROPVAL *props=NULL;
    DWORD bufsize=0;

    CEOID rid;
    WORD nProps;

    while (0!=(rid= CeReadRecordProps(h, CEDB_ALLOWREALLOC, &nProps, NULL,
    (BYTE*)&props, &bufsize)))
    {
        for (int i=0 ; i<nProps ; i++)
        {
            CeWriteRecordProps (destDBhandle, 0, 1, &props[i]);
        }
        LocalFree(props);
    }

}

int CFileApp::DBFunction(CFileDialog *pDlg, TCHAR SDPath[MAX_PATH])
{
    HANDLE hDBList;
    CEOID oidDB;

```

```

CEOID destoidDB;
CEOIDINFO poidInfo;

CEGUID guidVol;
CEGUID destGUID;
HANDLE DBhandle;
HANDLE destDBhandle;

char temp = '\\n';

CREATE_SYSTEMGUID(&guidVol);
CeMountDBVol (&destGUID, SDPath, OPEN_ALWAYS);

hDBList = CeFindFirstDatabaseEx(&guidVol, 0);

if (hDBList != INVALID_HANDLE_VALUE)
{
    oidDB = CeFindNextDatabaseEx(hDBList, &guidVol);

    while(oidDB)
    {
        DBhandle = CeOpenDatabaseEx(&guidVol, &oidDB, NULL, 0,
CEDB_AUTOINCREMENT, NULL);

        if (DBhandle != INVALID_HANDLE_VALUE)
        {
            CeOidGetInfoEx(&guidVol, oidDB, &poidInfo);

            pDlg->SetDlgItemText(IDC_EDIT1, (LPCTSTR)
poidInfo.infDatabase.szDbaseName);

            destoidDB = CeCreateDatabaseEx(&destGUID,
&poidInfo.infDatabase);

            destDBhandle = CeOpenDatabaseEx (&destGUID,
&destoidDB, NULL, 0, 0, NULL);

            DumpDatabaseByName(DBhandle, destDBhandle);
            pDlg->myPctrl.StepIt();

            CloseHandle(destDBhandle);

            CloseHandle(DBhandle);
        }
        oidDB = CeFindNextDatabaseEx(hDBList, &guidVol);
    }

    CloseHandle(hDBList);
}

CeUnmountDBVol(&destGUID);

```

```

        return 1;
    }

```

D.6 – Source code for Module 5

```

#include "stdafx.h"
#include "main.h"
#include "Dlg.h"
#include "pwinreg.h"
#include <windows.h>

////////////////////////////////////
// CFileApp

BEGIN_MESSAGE_MAP(CFileApp, CWinApp)

END_MESSAGE_MAP()

////////////////////////////////////
// CFileApp construction

CFileApp::CFileApp()
    : CWinApp()
{
    pDlg = NULL;
}

CFileApp::~~CFileApp()
{
    delete pDlg;
}

CFileApp theApp;

BOOL CFileApp::InitInstance()
{
    TCHAR temp[MAX_PATH];

    if (lstrcmp(m_lpCmdLine, TEXT("uninstall")) == 0)
    {
        //lstrcpy(temp, _T("\\Storage Card"));
        return FALSE;
    }

    if(DirNavigate(temp) == FALSE)
        return 0;

    int myProgressPos;

```

```

pDlg = new CFileDialog();

pDlg->m_bFullScreen = FALSE;

int iResponse = pDlg->Create(IDD_FILE_DIALOG, NULL);

//pDlg->SetDlgItemText(IDC_EDIT1, _T("To the HERO-Mobile..."));

lstrcat(temp, _T("\\Registry"));

BOOL SDDir = CreateDirectory(temp, NULL);

pDlg->SetDlgItemText(IDC_EDIT1, _T("Extracting Registry..."));

Sleep(1000);

if (!SDDir)
{
    pDlg->SetDlgItemText(IDC_EDIT1, _T("Registry folder exists"));
    Sleep(2000);
    delete this;
    return FALSE;
}

lstrcat(temp, _T("\\Registry.reg"));

RegCopyFile(temp);

//RegFunction(pDlg);

//RegSaveKey(HKEY_CLASSES_ROOT, "\\Storage Card\\temp.reg", NULL);

myProgressPos = pDlg->myPctrl.GetPos();
if (myProgressPos < 100)
{
    for(int tInker = myProgressPos; tInker < 100; tInker++)
    {
        pDlg->myPctrl.StepIt();
        Sleep(5);
    }
}

pDlg->SetDlgItemText(IDC_EDIT1, _T("Extracting Registry...Done"));

Sleep(2000);

delete this;

//}

// Since the dialog has been closed, return FALSE so that we exit the
// application, rather than start the application's message pump.
return FALSE;

```

```

}

BOOL CFileApp::DirNavigate(LPTSTR searchPath)
{

    HANDLE fileHandle;
    WIN32_FIND_DATA findData;

    //TCHAR searchPath[MAX_PATH];
    TCHAR ThePath[MAX_PATH];

    lstrcpy (searchPath, TEXT("\\*..*"));

    fileHandle = FindFirstFile (searchPath, &findData);

    if (fileHandle != INVALID_HANDLE_VALUE)
    {
        do
        {

            lstrcpy(searchPath, TEXT("\\"));

            lstrcat(searchPath, findData.cFileName);

            //MessageBox(NULL, searchPath, TEXT("Search"), MB_OK);

            if (findData.dwFileAttributes & FILE_ATTRIBUTE_DIRECTORY)
            {
                //if (findData.dwFileAttributes &
                FILE_ATTRIBUTE_TEMPORARY)
                //{

                    lstrcpy(ThePath, TEXT("\\"));
                    lstrcat(ThePath, findData.cFileName);
                    lstrcat(ThePath, TEXT("\\exists.here"));
                    //MessageBox(NULL, ThePath, TEXT("Search"),
                    MB_OK);

                    HANDLE temp = CreateFile(ThePath, GENERIC_READ,
                    0, NULL, OPEN_EXISTING, FILE_ATTRIBUTE_NORMAL, NULL);
                    if (temp != INVALID_HANDLE_VALUE)
                    {
                        CloseHandle(temp);
                        FindClose (fileHandle);
                        //MessageBox(NULL, searchPath,
                        TEXT("SD"), MB_OK);

                        return TRUE;
                    }
                }
            }

        }

        while (FindNextFile (fileHandle, &findData));
    }
}

```



```
    }  
    FindClose (fileHandle);  
  
    return FALSE;  
}
```

Appendix E – PocketPC Processes

Platform: PocketPC
Version: 4.20.1081
CPU: StrongARM

Process Memory Dump
filesys.exe

Virtual Memory Dump

Legend

C - Committed

R - Reserved

F - Free

RO - Read Only

RW - Read Write

WC - Write Copy

X - Execute

XR - Execute Read

XRW - Execute Read Write

XWC - Execute Write Copy

G - Guard

NA - No Access

NC - No Cache

04000000	1000 F NA
04010000	1000 R NA Image
04011000	30000 C RO Image
04041000	7000 C RW Image
04048000	3000 C RO Image
0404B000	5000 F NA
04050000	9000 R NA Private
04059000	1000 C RW Private
0405A000	1000 R NA Private
0405B000	1000 C RW Private
0405C000	1000 R NA Private
0405D000	3000 C RW Private
04060000	2F000 C RW Private
0408F000	1000 F NA
04090000	D000 R NA Private
0409D000	3000 C RW Private
040A0000	1000 C RW, NC Private
040A1000	F000 F NA
040B0000	1000 C RW, NC Private
040B1000	F000 F NA
040C0000	F000 R NA Private
040CF000	1000 C RW Private
040D0000	1E000 C RW Private
040EE000	11000 R NA Private
040FF000	1000 F NA
04100000	4000 C RW Private
04104000	C000 F NA
04110000	4000 C RW Private

04114000	C000 F NA
04120000	F000 R NA Private
0412F000	1000 C RW Private
04130000	10000 C RW Private
04140000	18D0000 F NA
05A10000	46000 R NA Image
05A56000	2A000 F NA
05A80000	1C000 R NA Image
05A9C000	B000 C RW Image
05AA7000	7000 R NA Image
05AAE000	1000 C RW Image
05AAF000	1000 R NA Image
05AB0000	1000 C RW Image
05AB1000	4000 R NA Image
05AB5000	11B000 F NA
05BD0000	44000 R NA Image
05C14000	10C000 F NA
05D20000	83000 R NA Image
05DA3000	3D000 F NA
05DE0000	62000 R NA Image
05E42000	8E000 F NA
05ED0000	61000 R NA Image
05F31000	2F000 F NA
05F60000	1000 R NA Image
05F61000	65000 C RO Image
05FC6000	1000 C RW Image
05FC7000	1B000 C RO Image
05FE2000	3000 R NA Image
05FE5000	B000 F NA
05FF0000	8000 R NA Image
05FF8000	2000 C RW Image
05FFA000	1000 R NA Image
05FFB000	1000 C RW Image
05FFC000	1000 R NA Image
05FFD000	1000 C RW Image
05FFE000	1000 R NA Image
05FFF000	1000 C RW Image

Process Heaps Dump

Default Heap

04060050	40 Fixed
04060090	10 Fixed
040600A0	20 Fixed
040600C0	20 Fixed
040600E0	1A0 Fixed
04060280	20 Fixed
040602A0	20 Fixed
040602C0	20 Fixed
040602E0	200 Fixed
040604E0	200 Fixed
040606E0	20 Fixed

04060700	10 Free	04065F90	200 Fixed
04060710	20 Fixed	04066190	200 Fixed
04060730	30 Fixed	04066390	200 Fixed
04060760	20 Fixed	04066590	200 Fixed
04060780	20 Fixed	04066790	200 Fixed
040607A0	20 Fixed	04066990	200 Fixed
040607C0	20 Fixed	04066B90	200 Fixed
040607E0	10 Free	04066D90	200 Fixed
040607F0	20 Fixed	04066F90	200 Fixed
04060810	30 Fixed	04067190	200 Fixed
04060840	250 Fixed	04067390	200 Fixed
04060A90	20 Fixed	04067590	200 Fixed
04060AB0	20 Fixed	04067790	200 Fixed
04060AD0	30 Fixed	04067990	200 Fixed
04060B00	9E0 Fixed	04067B90	200 Fixed
040614E0	240 Fixed	04067D90	200 Fixed
04061720	20 Fixed	04067F90	200 Fixed
04061740	10 Fixed	04068190	200 Fixed
04061750	20 Fixed	04068390	200 Fixed
04061770	20 Fixed	04068590	200 Fixed
04061790	200 Fixed	04068790	200 Fixed
04061990	200 Fixed	04068990	200 Fixed
04061B90	200 Fixed	04068B90	200 Fixed
04061D90	200 Fixed	04068D90	200 Fixed
04061F90	200 Fixed	04068F90	200 Fixed
04062190	200 Fixed	04069190	200 Fixed
04062390	200 Fixed	04069390	200 Fixed
04062590	200 Fixed	04069590	200 Fixed
04062790	200 Fixed	04069790	200 Fixed
04062990	200 Fixed	04069990	200 Fixed
04062B90	200 Fixed	04069B90	200 Fixed
04062D90	200 Fixed	04069D90	200 Fixed
04062F90	200 Fixed	04069F90	200 Fixed
04063190	200 Fixed	0406A190	200 Fixed
04063390	200 Fixed	0406A390	200 Fixed
04063590	200 Fixed	0406A590	200 Fixed
04063790	200 Fixed	0406A790	200 Fixed
04063990	200 Fixed	0406A990	200 Fixed
04063B90	200 Fixed	0406AB90	200 Fixed
04063D90	200 Fixed	0406AD90	200 Fixed
04063F90	200 Fixed	0406AF90	200 Fixed
04064190	200 Fixed	0406B190	200 Fixed
04064390	200 Fixed	0406B390	200 Fixed
04064590	200 Fixed	0406B590	200 Fixed
04064790	200 Fixed	0406B790	200 Fixed
04064990	200 Fixed	0406B990	200 Fixed
04064B90	200 Fixed	0406BB90	200 Fixed
04064D90	200 Fixed	0406BD90	200 Fixed
04064F90	200 Fixed	0406BF90	200 Fixed
04065190	200 Fixed	0406C190	200 Fixed
04065390	200 Fixed	0406C390	200 Fixed
04065590	200 Fixed	0406C590	200 Fixed
04065790	200 Fixed	0406C790	200 Fixed
04065990	200 Fixed	0406C990	200 Fixed
04065B90	200 Fixed	0406CB90	200 Fixed
04065D90	200 Fixed	0406CD90	200 Fixed

0406CF90	200 Fixed	04072C40	40 Fixed
0406D190	200 Fixed	04072C80	30 Fixed
0406D390	200 Fixed	04072CB0	20 Fixed
0406D590	200 Fixed	04072CD0	90 Fixed
0406D790	200 Fixed	04072D60	90 Fixed
0406D990	200 Fixed	04072DF0	780 Fixed
0406DB90	200 Fixed	04073570	720 Fixed
0406DD90	200 Fixed	04073C90	250 Fixed
0406DF90	200 Fixed	04073EE0	1040 Fixed
0406E190	200 Fixed	04074F20	50 Fixed
0406E390	200 Fixed	04074F70	30 Fixed
0406E590	200 Fixed	04074FA0	10 Free
0406E790	200 Fixed	04074FB0	350 Fixed
0406E990	200 Fixed	04075300	80 Fixed
0406EB90	200 Fixed	04075380	50 Fixed
0406ED90	200 Fixed	040753D0	40 Fixed
0406EF90	200 Fixed	04075410	20 Fixed
0406F190	200 Fixed	04075430	10 Free
0406F390	200 Fixed	04075440	40 Fixed
0406F590	200 Fixed	04075480	20 Fixed
0406F790	200 Fixed	040754A0	30 Fixed
0406F990	200 Fixed	040754D0	40 Fixed
0406FB90	200 Fixed	04075510	20 Fixed
0406FD90	200 Fixed	04075530	80 Fixed
0406FF90	200 Fixed	040755B0	70 Fixed
04070190	200 Fixed	04075620	40 Fixed
04070390	200 Fixed	04075660	20 Fixed
04070590	200 Fixed	04075680	80 Fixed
04070790	200 Fixed	04075700	50 Fixed
04070990	200 Fixed	04075750	40 Fixed
04070B90	200 Fixed	04075790	20 Fixed
04070D90	200 Fixed	040757B0	80 Fixed
04070F90	200 Fixed	04075830	50 Fixed
04071190	200 Fixed	04075880	40 Fixed
04071390	200 Fixed	040758C0	20 Fixed
04071590	200 Fixed	040758E0	80 Fixed
04071790	200 Fixed	04075960	50 Fixed
04071990	200 Fixed	040759B0	40 Fixed
04071B90	200 Fixed	040759F0	20 Fixed
04071D90	200 Fixed	04075A10	80 Fixed
04071F90	200 Fixed	04075A90	50 Fixed
04072190	200 Fixed	04075AE0	40 Fixed
04072390	200 Fixed	04075B20	20 Fixed
04072590	200 Fixed	04075B40	80 Fixed
04072790	20 Fixed	04075BC0	50 Fixed
040727B0	20 Fixed	04075C10	40 Fixed
040727D0	210 Fixed	04075C50	30 Fixed
040729E0	20 Fixed	04075C80	80 Fixed
04072A00	60 Fixed	04075D00	50 Fixed
04072A60	60 Fixed	04075D50	40 Fixed
04072AC0	20 Fixed	04075D90	20 Fixed
04072AE0	20 Fixed	04075DB0	80 Fixed
04072B00	40 Fixed	04075E30	50 Fixed
04072B40	30 Fixed	04075E80	40 Fixed
04072B70	80 Fixed	04075EC0	20 Fixed
04072BF0	50 Fixed	04075EE0	80 Fixed

04075F60	70 Fixed	04076F60	50 Fixed
04075FD0	80 Fixed	04076FB0	40 Fixed
04076050	70 Fixed	04076FF0	80 Fixed
040760C0	40 Fixed	04077070	50 Fixed
04076100	20 Fixed	040770C0	40 Fixed
04076120	80 Fixed	04077100	20 Fixed
040761A0	80 Fixed	04077120	80 Fixed
04076220	40 Fixed	040771A0	50 Fixed
04076260	20 Fixed	040771F0	40 Fixed
04076280	80 Fixed	04077230	20 Fixed
04076300	70 Fixed	04077250	80 Fixed
04076370	40 Fixed	040772D0	50 Fixed
040763B0	20 Fixed	04077320	40 Fixed
040763D0	80 Fixed	04077360	20 Fixed
04076450	50 Fixed	04077380	80 Fixed
040764A0	40 Fixed	04077400	50 Fixed
040764E0	20 Fixed	04077450	40 Fixed
04076500	40 Fixed	04077490	20 Fixed
04076540	20 Fixed	040774B0	80 Fixed
04076560	40 Fixed	04077530	50 Fixed
040765A0	30 Fixed	04077580	40 Fixed
040765D0	40 Fixed	040775C0	20 Fixed
04076610	20 Fixed	040775E0	80 Fixed
04076630	40 Fixed	04077660	50 Fixed
04076670	30 Fixed	040776B0	40 Fixed
040766A0	40 Fixed	040776F0	20 Fixed
040766E0	30 Fixed	04077710	80 Fixed
04076710	40 Fixed	04077790	50 Fixed
04076750	20 Fixed	040777E0	40 Fixed
04076770	40 Fixed	04077820	20 Fixed
040767B0	30 Fixed	04077840	80 Fixed
040767E0	40 Fixed	040778C0	50 Fixed
04076820	20 Fixed	04077910	40 Fixed
04076840	40 Fixed	04077950	20 Fixed
04076880	20 Fixed	04077970	80 Fixed
040768A0	80 Fixed	040779F0	50 Fixed
04076920	70 Fixed	04077A40	40 Fixed
04076990	40 Fixed	04077A80	20 Fixed
040769D0	20 Fixed	04077AA0	80 Fixed
040769F0	80 Fixed	04077B20	50 Fixed
04076A70	70 Fixed	04077B70	40 Fixed
04076AE0	40 Fixed	04077BB0	30 Fixed
04076B20	20 Fixed	04077BE0	80 Fixed
04076B40	40 Fixed	04077C60	70 Fixed
04076B80	80 Fixed	04077CD0	40 Fixed
04076C00	40 Fixed	04077D10	20 Fixed
04076C40	80 Fixed	04077D30	80 Fixed
04076CC0	40 Fixed	04077DB0	70 Fixed
04076D00	30 Fixed	04077E20	40 Fixed
04076D30	40 Fixed	04077E60	30 Fixed
04076D70	20 Fixed	04077E90	80 Fixed
04076D90	80 Fixed	04077F10	70 Fixed
04076E10	70 Fixed	04077F80	40 Fixed
04076E80	40 Fixed	04077FC0	20 Fixed
04076EC0	20 Fixed	04077FE0	80 Fixed
04076EE0	80 Fixed	04078060	70 Fixed

040780D0	40 Fixed	04079270	40 Fixed
04078110	30 Fixed	040792B0	30 Fixed
04078140	80 Fixed	040792E0	80 Fixed
040781C0	70 Fixed	04079360	80 Fixed
04078230	40 Fixed	040793E0	40 Fixed
04078270	30 Fixed	04079420	30 Fixed
040782A0	80 Fixed	04079450	80 Fixed
04078320	70 Fixed	040794D0	80 Fixed
04078390	40 Fixed	04079550	40 Fixed
040783D0	20 Fixed	04079590	30 Fixed
040783F0	80 Fixed	040795C0	80 Fixed
04078470	50 Fixed	04079640	50 Fixed
040784C0	40 Fixed	04079690	40 Fixed
04078500	20 Fixed	040796D0	30 Fixed
04078520	80 Fixed	04079700	80 Fixed
040785A0	50 Fixed	04079780	50 Fixed
040785F0	40 Fixed	040797D0	40 Fixed
04078630	20 Fixed	04079810	30 Fixed
04078650	80 Fixed	04079840	80 Fixed
040786D0	50 Fixed	040798C0	50 Fixed
04078720	40 Fixed	04079910	60 Fixed
04078760	20 Fixed	04079970	40 Fixed
04078780	80 Fixed	040799B0	60 Fixed
04078800	70 Fixed	04079A10	40 Fixed
04078870	40 Fixed	04079A50	60 Fixed
040788B0	30 Fixed	04079AB0	40 Fixed
040788E0	80 Fixed	04079AF0	70 Fixed
04078960	50 Fixed	04079B60	40 Fixed
040789B0	40 Fixed	04079BA0	70 Fixed
040789F0	30 Fixed	04079C10	40 Fixed
04078A20	80 Fixed	04079C50	70 Fixed
04078AA0	50 Fixed	04079CC0	40 Fixed
04078AF0	40 Fixed	04079D00	70 Fixed
04078B30	30 Fixed	04079D70	40 Fixed
04078B60	80 Fixed	04079DB0	90 Fixed
04078BE0	50 Fixed	04079E40	40 Fixed
04078C30	40 Fixed	04079E80	60 Fixed
04078C70	30 Fixed	04079EE0	40 Fixed
04078CA0	80 Fixed	04079F20	30 Fixed
04078D20	50 Fixed	04079F50	40 Fixed
04078D70	40 Fixed	04079F90	30 Fixed
04078DB0	20 Fixed	04079FC0	40 Fixed
04078DD0	80 Fixed	0407A000	40 Fixed
04078E50	50 Fixed	0407A040	40 Fixed
04078EA0	40 Fixed	0407A080	30 Fixed
04078EE0	20 Fixed	0407A0B0	40 Fixed
04078F00	80 Fixed	0407A0F0	30 Fixed
04078F80	50 Fixed	0407A120	40 Fixed
04078FD0	40 Fixed	0407A160	20 Fixed
04079010	30 Fixed	0407A180	40 Fixed
04079040	80 Fixed	0407A1C0	30 Fixed
040790C0	50 Fixed	0407A1F0	40 Fixed
04079110	40 Fixed	0407A230	20 Fixed
04079150	30 Fixed	0407A250	40 Fixed
04079180	80 Fixed	0407A290	20 Fixed
04079200	70 Fixed	0407A2B0	40 Fixed

0407A2F0	20 Fixed	0407AE90	20 Fixed
0407A310	40 Fixed	0407AEB0	80 Fixed
0407A350	30 Fixed	0407AF30	70 Fixed
0407A380	40 Fixed	0407AFA0	40 Fixed
0407A3C0	20 Fixed	0407AFE0	20 Fixed
0407A3E0	40 Fixed	0407B000	40 Fixed
0407A420	20 Fixed	0407B040	20 Fixed
0407A440	40 Fixed	0407B060	80 Fixed
0407A480	20 Fixed	0407B0E0	50 Fixed
0407A4A0	40 Fixed	0407B130	40 Fixed
0407A4E0	20 Fixed	0407B170	20 Fixed
0407A500	40 Fixed	0407B190	80 Fixed
0407A540	30 Fixed	0407B210	70 Fixed
0407A570	40 Fixed	0407B280	40 Fixed
0407A5B0	20 Fixed	0407B2C0	30 Fixed
0407A5D0	40 Fixed	0407B2F0	80 Fixed
0407A610	20 Fixed	0407B370	70 Fixed
0407A630	40 Fixed	0407B3E0	40 Fixed
0407A670	20 Fixed	0407B420	20 Fixed
0407A690	40 Fixed	0407B440	80 Fixed
0407A6D0	20 Fixed	0407B4C0	50 Fixed
0407A6F0	40 Fixed	0407B510	40 Fixed
0407A730	20 Fixed	0407B550	20 Fixed
0407A750	40 Fixed	0407B570	80 Fixed
0407A790	30 Fixed	0407B5F0	50 Fixed
0407A7C0	40 Fixed	0407B640	40 Fixed
0407A800	30 Fixed	0407B680	20 Fixed
0407A830	40 Fixed	0407B6A0	80 Fixed
0407A870	20 Fixed	0407B720	50 Fixed
0407A890	40 Fixed	0407B770	40 Fixed
0407A8D0	20 Fixed	0407B7B0	30 Fixed
0407A8F0	40 Fixed	0407B7E0	80 Fixed
0407A930	20 Fixed	0407B860	50 Fixed
0407A950	40 Fixed	0407B8B0	40 Fixed
0407A990	20 Fixed	0407B8F0	30 Fixed
0407A9B0	40 Fixed	0407B920	80 Fixed
0407A9F0	20 Fixed	0407B9A0	50 Fixed
0407AA10	40 Fixed	0407B9F0	40 Fixed
0407AA50	30 Fixed	0407BA30	20 Fixed
0407AA80	40 Fixed	0407BA50	80 Fixed
0407AAC0	20 Fixed	0407BAD0	50 Fixed
0407AAE0	40 Fixed	0407BB20	40 Fixed
0407AB20	30 Fixed	0407BB60	20 Fixed
0407AB50	40 Fixed	0407BB80	80 Fixed
0407AB90	30 Fixed	0407BC00	50 Fixed
0407ABC0	40 Fixed	0407BC50	40 Fixed
0407AC00	30 Fixed	0407BC90	30 Fixed
0407AC30	40 Fixed	0407BCC0	80 Fixed
0407AC70	30 Fixed	0407BD40	50 Fixed
0407ACA0	40 Fixed	0407BD90	40 Fixed
0407ACE0	20 Fixed	0407BDD0	20 Fixed
0407AD00	40 Fixed	0407BDF0	80 Fixed
0407AD40	20 Fixed	0407BE70	50 Fixed
0407AD60	80 Fixed	0407BEC0	40 Fixed
0407ADE0	70 Fixed	0407BF00	20 Fixed
0407AE50	40 Fixed	0407BF20	80 Fixed

0407BFA0	50 Fixed	0407D160	70 Fixed
0407BFF0	40 Fixed	0407D1D0	40 Fixed
0407C030	30 Fixed	0407D210	30 Fixed
0407C060	80 Fixed	0407D240	80 Fixed
0407C0E0	50 Fixed	0407D2C0	70 Fixed
0407C130	40 Fixed	0407D330	40 Fixed
0407C170	20 Fixed	0407D370	30 Fixed
0407C190	80 Fixed	0407D3A0	80 Fixed
0407C210	50 Fixed	0407D420	70 Fixed
0407C260	40 Fixed	0407D490	40 Fixed
0407C2A0	20 Fixed	0407D4D0	20 Fixed
0407C2C0	80 Fixed	0407D4F0	80 Fixed
0407C340	50 Fixed	0407D570	50 Fixed
0407C390	40 Fixed	0407D5C0	40 Fixed
0407C3D0	20 Fixed	0407D600	30 Fixed
0407C3F0	80 Fixed	0407D630	80 Fixed
0407C470	70 Fixed	0407D6B0	50 Fixed
0407C4E0	40 Fixed	0407D700	40 Fixed
0407C520	20 Fixed	0407D740	30 Fixed
0407C540	80 Fixed	0407D770	80 Fixed
0407C5C0	50 Fixed	0407D7F0	50 Fixed
0407C610	40 Fixed	0407D840	40 Fixed
0407C650	30 Fixed	0407D880	20 Fixed
0407C680	80 Fixed	0407D8A0	80 Fixed
0407C700	70 Fixed	0407D920	50 Fixed
0407C770	40 Fixed	0407D970	40 Fixed
0407C7B0	20 Fixed	0407D9B0	30 Fixed
0407C7D0	80 Fixed	0407D9E0	80 Fixed
0407C850	70 Fixed	0407DA60	50 Fixed
0407C8C0	40 Fixed	0407DAB0	40 Fixed
0407C900	20 Fixed	0407DAF0	20 Fixed
0407C920	80 Fixed	0407DB10	80 Fixed
0407C9A0	70 Fixed	0407DB90	70 Fixed
0407CA10	40 Fixed	0407DC00	40 Fixed
0407CA50	30 Fixed	0407DC40	20 Fixed
0407CA80	80 Fixed	0407DC60	80 Fixed
0407CB00	70 Fixed	0407DCE0	70 Fixed
0407CB70	40 Fixed	0407DD50	40 Fixed
0407CBB0	30 Fixed	0407DD90	20 Fixed
0407CBE0	80 Fixed	0407DDB0	80 Fixed
0407CC60	70 Fixed	0407DE30	70 Fixed
0407CCD0	40 Fixed	0407DEA0	40 Fixed
0407CD10	20 Fixed	0407DEE0	20 Fixed
0407CD30	80 Fixed	0407DF00	80 Fixed
0407CDB0	70 Fixed	0407DF80	70 Fixed
0407CE20	40 Fixed	0407DFF0	40 Fixed
0407CE60	20 Fixed	0407E030	20 Fixed
0407CE80	80 Fixed	0407E050	80 Fixed
0407CF00	50 Fixed	0407E0D0	70 Fixed
0407CF50	40 Fixed	0407E140	40 Fixed
0407CF90	20 Fixed	0407E180	30 Fixed
0407CFB0	80 Fixed	0407E1B0	80 Fixed
0407D030	50 Fixed	0407E230	50 Fixed
0407D080	40 Fixed	0407E280	40 Fixed
0407D0C0	20 Fixed	0407E2C0	20 Fixed
0407D0E0	80 Fixed	0407E2E0	80 Fixed

0407E360	50 Fixed	0407F510	70 Fixed
0407E3B0	40 Fixed	0407F580	40 Fixed
0407E3F0	20 Fixed	0407F5C0	30 Fixed
0407E410	80 Fixed	0407F5F0	80 Fixed
0407E490	50 Fixed	0407F670	50 Fixed
0407E4E0	40 Fixed	0407F6C0	40 Fixed
0407E520	20 Fixed	0407F700	20 Fixed
0407E540	80 Fixed	0407F720	80 Fixed
0407E5C0	50 Fixed	0407F7A0	50 Fixed
0407E610	40 Fixed	0407F7F0	40 Fixed
0407E650	30 Fixed	0407F830	20 Fixed
0407E680	80 Fixed	0407F850	80 Fixed
0407E700	50 Fixed	0407F8D0	50 Fixed
0407E750	40 Fixed	0407F920	40 Fixed
0407E790	30 Fixed	0407F960	20 Fixed
0407E7C0	80 Fixed	0407F980	80 Fixed
0407E840	50 Fixed	0407FA00	50 Fixed
0407E890	40 Fixed	0407FA50	40 Fixed
0407E8D0	20 Fixed	0407FA90	20 Fixed
0407E8F0	80 Fixed	0407FAB0	80 Fixed
0407E970	70 Fixed	0407FB30	50 Fixed
0407E9E0	40 Fixed	0407FB80	40 Fixed
0407EA20	30 Fixed	0407FBC0	20 Fixed
0407EA50	80 Fixed	0407FBE0	80 Fixed
0407EAD0	70 Fixed	0407FC60	70 Fixed
0407EB40	40 Fixed	0407FCD0	40 Fixed
0407EB80	20 Fixed	0407FD10	20 Fixed
0407EBA0	80 Fixed	0407FD30	80 Fixed
0407EC20	70 Fixed	0407FDB0	70 Fixed
0407EC90	40 Fixed	0407FE20	40 Fixed
0407ECD0	30 Fixed	0407FE60	30 Fixed
0407ED00	80 Fixed	0407FE90	80 Fixed
0407ED80	70 Fixed	0407FF10	50 Fixed
0407EDF0	40 Fixed	0407FF60	40 Fixed
0407EE30	20 Fixed	0407FFA0	20 Fixed
0407EE50	80 Fixed	0407FFC0	80 Fixed
0407EED0	70 Fixed	04080040	70 Fixed
0407EF40	40 Fixed	040800B0	40 Fixed
0407EF80	20 Fixed	040800F0	20 Fixed
0407EFA0	80 Fixed	04080110	80 Fixed
0407F020	50 Fixed	04080190	70 Fixed
0407F070	40 Fixed	04080200	40 Fixed
0407F0B0	20 Fixed	04080240	20 Fixed
0407F0D0	80 Fixed	04080260	80 Fixed
0407F150	70 Fixed	040802E0	70 Fixed
0407F1C0	40 Fixed	04080350	40 Fixed
0407F200	30 Fixed	04080390	30 Fixed
0407F230	80 Fixed	040803C0	80 Fixed
0407F2B0	50 Fixed	04080440	50 Fixed
0407F300	40 Fixed	04080490	40 Fixed
0407F340	20 Fixed	040804D0	20 Fixed
0407F360	80 Fixed	040804F0	80 Fixed
0407F3E0	50 Fixed	04080570	50 Fixed
0407F430	40 Fixed	040805C0	40 Fixed
0407F470	20 Fixed	04080600	30 Fixed
0407F490	80 Fixed	04080630	80 Fixed

040806B0	50 Fixed	04081870	70 Fixed
04080700	40 Fixed	040818E0	40 Fixed
04080740	30 Fixed	04081920	30 Fixed
04080770	80 Fixed	04081950	80 Fixed
040807F0	70 Fixed	040819D0	50 Fixed
04080860	40 Fixed	04081A20	40 Fixed
040808A0	20 Fixed	04081A60	20 Fixed
040808C0	80 Fixed	04081A80	80 Fixed
04080940	50 Fixed	04081B00	50 Fixed
04080990	40 Fixed	04081B50	10 Free
040809D0	20 Fixed	04081B60	40 Fixed
040809F0	80 Fixed	04081BA0	20 Fixed
04080A70	70 Fixed	04081BC0	40 Fixed
04080AE0	40 Fixed	04081C00	30 Fixed
04080B20	20 Fixed	04081C30	40 Fixed
04080B40	80 Fixed	04081C70	30 Fixed
04080BC0	70 Fixed	04081CA0	40 Fixed
04080C30	40 Fixed	04081CE0	20 Fixed
04080C70	30 Fixed	04081D00	40 Fixed
04080CA0	80 Fixed	04081D40	20 Fixed
04080D20	50 Fixed	04081D60	40 Fixed
04080D70	40 Fixed	04081DA0	20 Fixed
04080DB0	20 Fixed	04081DC0	40 Fixed
04080DD0	80 Fixed	04081E00	30 Fixed
04080E50	50 Fixed	04081E30	40 Fixed
04080EA0	40 Fixed	04081E70	20 Fixed
04080EE0	30 Fixed	04081E90	20 Fixed
04080F10	80 Fixed	04081EB0	40 Fixed
04080F90	50 Fixed	04081EF0	20 Fixed
04080FE0	40 Fixed	04081F10	80 Fixed
04081020	30 Fixed	04081F90	70 Fixed
04081050	80 Fixed	04082000	40 Fixed
040810D0	80 Fixed	04082040	30 Fixed
04081150	40 Fixed	04082070	80 Fixed
04081190	20 Fixed	040820F0	50 Fixed
040811B0	80 Fixed	04082140	40 Fixed
04081230	50 Fixed	04082180	20 Fixed
04081280	40 Fixed	040821A0	80 Fixed
040812C0	20 Fixed	04082220	50 Fixed
040812E0	80 Fixed	04082270	40 Fixed
04081360	70 Fixed	040822B0	30 Fixed
040813D0	40 Fixed	040822E0	80 Fixed
04081410	20 Fixed	04082360	50 Fixed
04081430	80 Fixed	040823B0	40 Fixed
040814B0	70 Fixed	040823F0	20 Fixed
04081520	40 Fixed	04082410	80 Fixed
04081560	30 Fixed	04082490	50 Fixed
04081590	80 Fixed	040824E0	40 Fixed
04081610	50 Fixed	04082520	20 Fixed
04081660	40 Fixed	04082540	40 Fixed
040816A0	20 Fixed	04082580	20 Fixed
040816C0	80 Fixed	040825A0	10 Free
04081740	50 Fixed	040825B0	30 Fixed
04081790	40 Fixed	040825E0	40 Fixed
040817D0	20 Fixed	04082620	30 Fixed
040817F0	80 Fixed	04082650	40 Fixed

04082690	20 Fixed	04083160	20 Fixed
040826B0	40 Fixed	04083180	40 Fixed
040826F0	20 Fixed	040831C0	20 Fixed
04082710	40 Fixed	040831E0	40 Fixed
04082750	20 Fixed	04083220	20 Fixed
04082770	40 Fixed	04083240	40 Fixed
040827B0	20 Fixed	04083280	20 Fixed
040827D0	40 Fixed	040832A0	40 Fixed
04082810	20 Fixed	040832E0	20 Fixed
04082830	40 Fixed	04083300	40 Fixed
04082870	20 Fixed	04083340	20 Fixed
04082890	40 Fixed	04083360	40 Fixed
040828D0	20 Fixed	040833A0	20 Fixed
040828F0	40 Fixed	040833C0	40 Fixed
04082930	20 Fixed	04083400	20 Fixed
04082950	40 Fixed	04083420	40 Fixed
04082990	20 Fixed	04083460	20 Fixed
040829B0	40 Fixed	04083480	40 Fixed
040829F0	20 Fixed	040834C0	20 Fixed
04082A10	40 Fixed	040834E0	40 Fixed
04082A50	20 Fixed	04083520	20 Fixed
04082A70	40 Fixed	04083540	40 Fixed
04082AB0	20 Fixed	04083580	20 Fixed
04082AD0	40 Fixed	040835A0	40 Fixed
04082B10	20 Fixed	040835E0	30 Fixed
04082B30	40 Fixed	04083610	40 Fixed
04082B70	30 Fixed	04083650	20 Fixed
04082BA0	40 Fixed	04083670	40 Fixed
04082BE0	20 Fixed	040836B0	20 Fixed
04082C00	40 Fixed	040836D0	40 Fixed
04082C40	20 Fixed	04083710	30 Fixed
04082C60	40 Fixed	04083740	40 Fixed
04082CA0	20 Fixed	04083780	20 Fixed
04082CC0	40 Fixed	040837A0	40 Fixed
04082D00	20 Fixed	040837E0	30 Fixed
04082D20	40 Fixed	04083810	40 Fixed
04082D60	20 Fixed	04083850	20 Fixed
04082D80	40 Fixed	04083870	40 Fixed
04082DC0	20 Fixed	040838B0	30 Fixed
04082DE0	40 Fixed	040838E0	40 Fixed
04082E20	30 Fixed	04083920	20 Fixed
04082E50	40 Fixed	04083940	40 Fixed
04082E90	30 Fixed	04083980	20 Fixed
04082EC0	40 Fixed	040839A0	40 Fixed
04082F00	20 Fixed	040839E0	20 Fixed
04082F20	40 Fixed	04083A00	40 Fixed
04082F60	30 Fixed	04083A40	20 Fixed
04082F90	40 Fixed	04083A60	40 Fixed
04082FD0	30 Fixed	04083AA0	30 Fixed
04083000	40 Fixed	04083AD0	40 Fixed
04083040	20 Fixed	04083B10	20 Fixed
04083060	40 Fixed	04083B30	40 Fixed
040830A0	20 Fixed	04083B70	20 Fixed
040830C0	40 Fixed	04083B90	40 Fixed
04083100	20 Fixed	04083BD0	30 Fixed
04083120	40 Fixed	04083C00	40 Fixed

04083C40	30 Fixed	040849A0	50 Fixed
04083C70	40 Fixed	040849F0	40 Fixed
04083CB0	20 Fixed	04084A30	20 Fixed
04083CD0	40 Fixed	04084A50	80 Fixed
04083D10	20 Fixed	04084AD0	50 Fixed
04083D30	40 Fixed	04084B20	40 Fixed
04083D70	20 Fixed	04084B60	30 Fixed
04083D90	40 Fixed	04084B90	80 Fixed
04083DD0	30 Fixed	04084C10	50 Fixed
04083E00	40 Fixed	04084C60	40 Fixed
04083E40	20 Fixed	04084CA0	20 Fixed
04083E60	40 Fixed	04084CC0	80 Fixed
04083EA0	20 Fixed	04084D40	50 Fixed
04083EC0	40 Fixed	04084D90	40 Fixed
04083F00	30 Fixed	04084DD0	20 Fixed
04083F30	40 Fixed	04084DF0	80 Fixed
04083F70	30 Fixed	04084E70	50 Fixed
04083FA0	40 Fixed	04084EC0	40 Fixed
04083FE0	30 Fixed	04084F00	20 Fixed
04084010	40 Fixed	04084F20	80 Fixed
04084050	30 Fixed	04084FA0	50 Fixed
04084080	40 Fixed	04084FF0	80 Fixed
040840C0	30 Fixed	04085070	50 Fixed
040840F0	40 Fixed	040850C0	40 Fixed
04084130	30 Fixed	04085100	20 Fixed
04084160	40 Fixed	04085120	80 Fixed
040841A0	30 Fixed	040851A0	50 Fixed
040841D0	40 Fixed	040851F0	40 Fixed
04084210	30 Fixed	04085230	20 Fixed
04084240	40 Fixed	04085250	80 Fixed
04084280	20 Fixed	040852D0	50 Fixed
040842A0	40 Fixed	04085320	40 Fixed
040842E0	20 Fixed	04085360	20 Fixed
04084300	40 Fixed	04085380	80 Fixed
04084340	30 Fixed	04085400	50 Fixed
04084370	40 Fixed	04085450	40 Fixed
040843B0	30 Fixed	04085490	20 Fixed
040843E0	40 Fixed	040854B0	80 Fixed
04084420	30 Fixed	04085530	50 Fixed
04084450	80 Fixed	04085580	40 Fixed
040844D0	50 Fixed	040855C0	20 Fixed
04084520	40 Fixed	040855E0	80 Fixed
04084560	30 Fixed	04085660	50 Fixed
04084590	80 Fixed	040856B0	40 Fixed
04084610	50 Fixed	040856F0	20 Fixed
04084660	40 Fixed	04085710	80 Fixed
040846A0	20 Fixed	04085790	50 Fixed
040846C0	80 Fixed	040857E0	40 Fixed
04084740	50 Fixed	04085820	20 Fixed
04084790	40 Fixed	04085840	80 Fixed
040847D0	20 Fixed	040858C0	50 Fixed
040847F0	80 Fixed	04085910	40 Fixed
04084870	50 Fixed	04085950	20 Fixed
040848C0	40 Fixed	04085970	80 Fixed
04084900	20 Fixed	040859F0	50 Fixed
04084920	80 Fixed	04085A40	40 Fixed

04085A80	20 Fixed	04086C10	30 Fixed
04085AA0	80 Fixed	04086C40	40 Fixed
04085B20	70 Fixed	04086C80	30 Fixed
04085B90	40 Fixed	04086CB0	40 Fixed
04085BD0	20 Fixed	04086CF0	20 Fixed
04085BF0	80 Fixed	04086D10	40 Fixed
04085C70	70 Fixed	04086D50	20 Fixed
04085CE0	40 Fixed	04086D70	40 Fixed
04085D20	20 Fixed	04086DB0	20 Fixed
04085D40	80 Fixed	04086DD0	40 Fixed
04085DC0	70 Fixed	04086E10	30 Fixed
04085E30	40 Fixed	04086E40	40 Fixed
04085E70	20 Fixed	04086E80	20 Fixed
04085E90	80 Fixed	04086EA0	40 Fixed
04085F10	70 Fixed	04086EE0	30 Fixed
04085F80	40 Fixed	04086F10	40 Fixed
04085FC0	20 Fixed	04086F50	30 Fixed
04085FE0	80 Fixed	04086F80	40 Fixed
04086060	70 Fixed	04086FC0	30 Fixed
040860D0	40 Fixed	04086FF0	40 Fixed
04086110	20 Fixed	04087030	30 Fixed
04086130	80 Fixed	04087060	40 Fixed
040861B0	70 Fixed	040870A0	30 Fixed
04086220	40 Fixed	040870D0	20 Fixed
04086260	20 Fixed	040870F0	40 Fixed
04086280	80 Fixed	04087130	30 Fixed
04086300	70 Fixed	04087160	80 Fixed
04086370	40 Fixed	040871E0	70 Fixed
040863B0	20 Fixed	04087250	40 Fixed
040863D0	80 Fixed	04087290	30 Fixed
04086450	70 Fixed	040872C0	80 Fixed
040864C0	40 Fixed	04087340	80 Fixed
04086500	20 Fixed	040873C0	40 Fixed
04086520	80 Fixed	04087400	20 Fixed
040865A0	70 Fixed	04087420	80 Fixed
04086610	40 Fixed	040874A0	70 Fixed
04086650	20 Fixed	04087510	40 Fixed
04086670	80 Fixed	04087550	30 Fixed
040866F0	70 Fixed	04087580	80 Fixed
04086760	40 Fixed	04087600	70 Fixed
040867A0	20 Fixed	04087670	40 Fixed
040867C0	80 Fixed	040876B0	20 Fixed
04086840	70 Fixed	040876D0	80 Fixed
040868B0	40 Fixed	04087750	70 Fixed
040868F0	30 Fixed	040877C0	40 Fixed
04086920	80 Fixed	04087800	20 Fixed
040869A0	70 Fixed	04087820	80 Fixed
04086A10	40 Fixed	040878A0	50 Fixed
04086A50	20 Fixed	040878F0	40 Fixed
04086A70	40 Fixed	04087930	20 Fixed
04086AB0	30 Fixed	04087950	80 Fixed
04086AE0	40 Fixed	040879D0	50 Fixed
04086B20	40 Fixed	04087A20	40 Fixed
04086B60	40 Fixed	04087A60	30 Fixed
04086BA0	30 Fixed	04087A90	80 Fixed
04086BD0	40 Fixed	04087B10	70 Fixed

04087B80	40 Fixed	04088D60	40 Fixed
04087BC0	20 Fixed	04088DA0	20 Fixed
04087BE0	80 Fixed	04088DC0	80 Fixed
04087C60	50 Fixed	04088E40	70 Fixed
04087CB0	40 Fixed	04088EB0	40 Fixed
04087CF0	20 Fixed	04088EF0	20 Fixed
04087D10	80 Fixed	04088F10	80 Fixed
04087D90	50 Fixed	04088F90	70 Fixed
04087DE0	40 Fixed	04089000	40 Fixed
04087E20	20 Fixed	04089040	20 Fixed
04087E40	80 Fixed	04089060	80 Fixed
04087EC0	50 Fixed	040890E0	70 Fixed
04087F10	40 Fixed	04089150	40 Fixed
04087F50	30 Fixed	04089190	20 Fixed
04087F80	80 Fixed	040891B0	80 Fixed
04088000	70 Fixed	04089230	70 Fixed
04088070	40 Fixed	040892A0	40 Fixed
040880B0	30 Fixed	040892E0	20 Fixed
040880E0	80 Fixed	04089300	80 Fixed
04088160	50 Fixed	04089380	70 Fixed
040881B0	40 Fixed	040893F0	40 Fixed
040881F0	30 Fixed	04089430	30 Fixed
04088220	80 Fixed	04089460	80 Fixed
040882A0	70 Fixed	040894E0	50 Fixed
04088310	40 Fixed	04089530	40 Fixed
04088350	30 Fixed	04089570	30 Fixed
04088380	80 Fixed	040895A0	80 Fixed
04088400	50 Fixed	04089620	50 Fixed
04088450	40 Fixed	04089670	40 Fixed
04088490	20 Fixed	040896B0	30 Fixed
040884B0	80 Fixed	040896E0	80 Fixed
04088530	70 Fixed	04089760	E0 Fixed
040885A0	40 Fixed	04089840	40 Fixed
040885E0	30 Fixed	04089880	30 Fixed
04088610	80 Fixed	040898B0	80 Fixed
04088690	50 Fixed	04089930	50 Fixed
040886E0	40 Fixed	04089980	40 Fixed
04088720	30 Fixed	040899C0	20 Fixed
04088750	80 Fixed	040899E0	80 Fixed
040887D0	50 Fixed	04089A60	50 Fixed
04088820	40 Fixed	04089AB0	40 Fixed
04088860	20 Fixed	04089AF0	30 Fixed
04088880	80 Fixed	04089B20	80 Fixed
04088900	70 Fixed	04089BA0	70 Fixed
04088970	40 Fixed	04089C10	40 Fixed
040889B0	20 Fixed	04089C50	20 Fixed
040889D0	80 Fixed	04089C70	80 Fixed
04088A50	70 Fixed	04089CF0	50 Fixed
04088AC0	40 Fixed	04089D40	40 Fixed
04088B00	20 Fixed	04089D80	30 Fixed
04088B20	80 Fixed	04089DB0	80 Fixed
04088BA0	70 Fixed	04089E30	70 Fixed
04088C10	40 Fixed	04089EA0	40 Fixed
04088C50	20 Fixed	04089EE0	20 Fixed
04088C70	80 Fixed	04089F00	80 Fixed
04088CF0	70 Fixed	04089F80	70 Fixed

04089FF0	40 Fixed	0408AFD0	40 Fixed
0408A030	20 Fixed	0408B010	30 Fixed
0408A050	80 Fixed	0408B040	40 Fixed
0408A0D0	70 Fixed	0408B080	20 Fixed
0408A140	40 Fixed	0408B0A0	30 Fixed
0408A180	30 Fixed	0408B0D0	40 Fixed
0408A1B0	80 Fixed	0408B110	20 Fixed
0408A230	50 Fixed	0408B130	80 Fixed
0408A280	40 Fixed	0408B1B0	50 Fixed
0408A2C0	20 Fixed	0408B200	40 Fixed
0408A2E0	80 Fixed	0408B240	30 Fixed
0408A360	70 Fixed	0408B270	80 Fixed
0408A3D0	40 Fixed	0408B2F0	50 Fixed
0408A410	30 Fixed	0408B340	40 Fixed
0408A440	80 Fixed	0408B380	30 Fixed
0408A4C0	70 Fixed	0408B3B0	40 Fixed
0408A530	40 Fixed	0408B3F0	20 Fixed
0408A570	30 Fixed	0408B410	40 Fixed
0408A5A0	80 Fixed	0408B450	30 Fixed
0408A620	80 Fixed	0408B480	40 Fixed
0408A6A0	40 Fixed	0408B4C0	20 Fixed
0408A6E0	30 Fixed	0408B4E0	40 Fixed
0408A710	80 Fixed	0408B520	30 Fixed
0408A790	80 Fixed	0408B550	40 Fixed
0408A810	40 Fixed	0408B590	30 Fixed
0408A850	30 Fixed	0408B5C0	40 Fixed
0408A880	80 Fixed	0408B600	20 Fixed
0408A900	A0 Fixed	0408B620	40 Fixed
0408A9A0	40 Fixed	0408B660	20 Fixed
0408A9E0	40 Fixed	0408B680	40 Fixed
0408AA20	40 Fixed	0408B6C0	30 Fixed
0408AA60	30 Fixed	0408B6F0	40 Fixed
0408AA90	40 Fixed	0408B730	20 Fixed
0408AAD0	30 Fixed	0408B750	40 Fixed
0408AB00	40 Fixed	0408B790	30 Fixed
0408AB40	30 Fixed	0408B7C0	40 Fixed
0408AB70	40 Fixed	0408B800	30 Fixed
0408ABB0	30 Fixed	0408B830	40 Fixed
0408ABE0	40 Fixed	0408B870	20 Fixed
0408AC20	30 Fixed	0408B890	40 Fixed
0408AC50	40 Fixed	0408B8D0	30 Fixed
0408AC90	30 Fixed	0408B900	40 Fixed
0408ACC0	40 Fixed	0408B940	30 Fixed
0408AD00	30 Fixed	0408B970	40 Fixed
0408AD30	40 Fixed	0408B9B0	30 Fixed
0408AD70	30 Fixed	0408B9E0	40 Fixed
0408ADA0	40 Fixed	0408BA20	20 Fixed
0408ADE0	30 Fixed	0408BA40	40 Fixed
0408AE10	40 Fixed	0408BA80	20 Fixed
0408AE50	30 Fixed	0408BAA0	40 Fixed
0408AE80	40 Fixed	0408BAE0	20 Fixed
0408AEC0	30 Fixed	0408BB00	40 Fixed
0408AEF0	40 Fixed	0408BB40	30 Fixed
0408AF30	30 Fixed	0408BB70	40 Fixed
0408AF60	40 Fixed	0408BBB0	20 Fixed
0408AFA0	30 Fixed	0408BBD0	40 Fixed

0408BC10	20 Fixed	0408C760	20 Fixed
0408BC30	40 Fixed	0408C780	40 Fixed
0408BC70	30 Fixed	0408C7C0	20 Fixed
0408BCA0	40 Fixed	0408C7E0	40 Fixed
0408BCE0	20 Fixed	0408C820	20 Fixed
0408BD00	40 Fixed	0408C840	40 Fixed
0408BD40	30 Fixed	0408C880	20 Fixed
0408BD70	40 Fixed	0408C8A0	40 Fixed
0408BDB0	20 Fixed	0408C8E0	30 Fixed
0408BDD0	40 Fixed	0408C910	40 Fixed
0408BE10	20 Fixed	0408C950	30 Fixed
0408BE30	40 Fixed	0408C980	40 Fixed
0408BE70	30 Fixed	0408C9C0	30 Fixed
0408BEA0	40 Fixed	0408C9F0	40 Fixed
0408BEE0	30 Fixed	0408CA30	20 Fixed
0408BF10	40 Fixed	0408CA50	40 Fixed
0408BF50	30 Fixed	0408CA90	20 Fixed
0408BF80	40 Fixed	0408CAB0	40 Fixed
0408BFC0	30 Fixed	0408CAF0	20 Fixed
0408BFF0	40 Fixed	0408CB10	40 Fixed
0408C030	20 Fixed	0408CB50	20 Fixed
0408C050	40 Fixed	0408CB70	40 Fixed
0408C090	30 Fixed	0408CBB0	20 Fixed
0408C0C0	40 Fixed	0408CBD0	40 Fixed
0408C100	30 Fixed	0408CC10	20 Fixed
0408C130	40 Fixed	0408CC30	40 Fixed
0408C170	20 Fixed	0408CC70	30 Fixed
0408C190	40 Fixed	0408CCA0	40 Fixed
0408C1D0	20 Fixed	0408CCE0	20 Fixed
0408C1F0	40 Fixed	0408CD00	40 Fixed
0408C230	20 Fixed	0408CD40	20 Fixed
0408C250	40 Fixed	0408CD60	40 Fixed
0408C290	30 Fixed	0408CDA0	20 Fixed
0408C2C0	40 Fixed	0408CDC0	40 Fixed
0408C300	20 Fixed	0408CE00	20 Fixed
0408C320	40 Fixed	0408CE20	40 Fixed
0408C360	30 Fixed	0408CE60	20 Fixed
0408C390	40 Fixed	0408CE80	40 Fixed
0408C3D0	20 Fixed	0408CEC0	20 Fixed
0408C3F0	40 Fixed	0408CEE0	40 Fixed
0408C430	20 Fixed	0408CF20	20 Fixed
0408C450	40 Fixed	0408CF40	40 Fixed
0408C490	20 Fixed	0408CF80	20 Fixed
0408C4B0	40 Fixed	0408CFA0	40 Fixed
0408C4F0	30 Fixed	0408CFE0	30 Fixed
0408C520	40 Fixed	0408D010	40 Fixed
0408C560	20 Fixed	0408D050	40 Fixed
0408C580	40 Fixed	0408D090	40 Fixed
0408C5C0	30 Fixed	0408D0D0	20 Fixed
0408C5F0	40 Fixed	0408D0F0	40 Fixed
0408C630	30 Fixed	0408D130	20 Fixed
0408C660	40 Fixed	0408D150	40 Fixed
0408C6A0	20 Fixed	0408D190	20 Fixed
0408C6C0	40 Fixed	0408D1B0	40 Fixed
0408C700	20 Fixed	0408D1F0	20 Fixed
0408C720	40 Fixed	0408D210	40 Fixed

0408D250	20 Fixed	0408E290	20 Fixed
0408D270	40 Fixed	0408E2B0	80 Fixed
0408D2B0	30 Fixed	0408E330	70 Fixed
0408D2E0	40 Fixed	0408E3A0	40 Fixed
0408D320	20 Fixed	0408E3E0	30 Fixed
0408D340	40 Fixed	0408E410	80 Fixed
0408D380	30 Fixed	0408E490	70 Fixed
0408D3B0	40 Fixed	0408E500	40 Fixed
0408D3F0	30 Fixed	0408E540	30 Fixed
0408D420	40 Fixed	0408E570	80 Fixed
0408D460	20 Fixed	0408E5F0	70 Fixed
0408D480	40 Fixed	0408E660	40 Fixed
0408D4C0	30 Fixed	0408E6A0	30 Fixed
0408D4F0	80 Fixed	0408E6D0	80 Fixed
0408D570	50 Fixed	0408E750	70 Fixed
0408D5C0	40 Fixed	0408E7C0	40 Fixed
0408D600	20 Fixed	0408E800	30 Fixed
0408D620	80 Fixed	0408E830	80 Fixed
0408D6A0	50 Fixed	0408E8B0	70 Fixed
0408D6F0	40 Fixed	0408E920	40 Fixed
0408D730	20 Fixed	0408E960	30 Fixed
0408D750	80 Fixed	0408E990	80 Fixed
0408D7D0	50 Fixed	0408EA10	70 Fixed
0408D820	40 Fixed	0408EA80	40 Fixed
0408D860	20 Fixed	0408EAC0	20 Fixed
0408D880	80 Fixed	0408EAE0	80 Fixed
0408D900	50 Fixed	0408EB60	70 Fixed
0408D950	40 Fixed	0408EBD0	40 Fixed
0408D990	20 Fixed	0408EC10	30 Fixed
0408D9B0	80 Fixed	0408EC40	80 Fixed
0408DA30	50 Fixed	0408ECC0	70 Fixed
0408DA80	40 Fixed	0408ED30	40 Fixed
0408DAC0	20 Fixed	0408ED70	30 Fixed
0408DAE0	80 Fixed	0408EDA0	80 Fixed
0408DB60	50 Fixed	0408EE20	70 Fixed
0408DBB0	40 Fixed	0408EE90	40 Fixed
0408DBF0	20 Fixed	0408EED0	30 Fixed
0408DC10	80 Fixed	0408EF00	80 Fixed
0408DC90	50 Fixed	0408EF80	50 Fixed
0408DCE0	40 Fixed	0408EFD0	30 Fixed
0408DD20	30 Fixed	040D0020	80 Fixed
0408DD50	80 Fixed	040D00A0	50 Fixed
0408DDD0	50 Fixed	040D00F0	40 Fixed
0408DE20	40 Fixed	040D0130	30 Fixed
0408DE60	30 Fixed	040D0160	80 Fixed
0408DE90	80 Fixed	040D01E0	50 Fixed
0408DF10	70 Fixed	040D0230	40 Fixed
0408DF80	40 Fixed	040D0270	80 Fixed
0408DFC0	30 Fixed	040D02F0	70 Fixed
0408DFF0	80 Fixed	040D0360	40 Fixed
0408E070	70 Fixed	040D03A0	80 Fixed
0408E0E0	40 Fixed	040D0420	70 Fixed
0408E120	40 Fixed	040D0490	40 Fixed
0408E160	80 Fixed	040D04D0	30 Fixed
0408E1E0	70 Fixed	040D0500	80 Fixed
0408E250	40 Fixed	040D0580	50 Fixed

040D05D0	40 Fixed
040D0610	30 Fixed
040D0640	80 Fixed
040D06C0	50 Fixed
040D0710	40 Fixed
040D0750	30 Fixed
040D0780	80 Fixed
040D0800	70 Fixed
040D0870	40 Fixed
040D08B0	80 Fixed
040D0930	50 Fixed
040D0980	40 Fixed
040D09C0	30 Fixed
040D09F0	80 Fixed
040D0A70	50 Fixed
040D0AC0	40 Fixed
040D0B00	80 Fixed
040D0B80	70 Fixed
040D0BF0	40 Fixed
040D0C30	80 Fixed
040D0CB0	50 Fixed
040D0D00	40 Fixed
040D0D40	80 Fixed
040D0DC0	50 Fixed
040D0E10	40 Fixed
040D0E50	80 Fixed
040D0ED0	50 Fixed
040D0F20	40 Fixed
040D0F60	30 Fixed
040D0F90	80 Fixed
040D1010	70 Fixed
040D1080	40 Fixed
040D10C0	30 Fixed
040D10F0	80 Fixed
040D1170	50 Fixed
040D11C0	40 Fixed
040D1200	30 Fixed
040D1230	80 Fixed
040D12B0	70 Fixed
040D1320	40 Fixed
040D1360	30 Fixed
040D1390	80 Fixed
040D1410	50 Fixed
040D1460	40 Fixed
040D14A0	30 Fixed
040D14D0	80 Fixed
040D1550	50 Fixed
040D15A0	40 Fixed
040D15E0	30 Fixed
040D1610	80 Fixed
040D1690	70 Fixed
040D1700	40 Fixed
040D1740	30 Fixed
040D1770	80 Fixed
040D17F0	80 Fixed
040D1870	40 Fixed

040D18B0	30 Fixed
040D18E0	80 Fixed
040D1960	80 Fixed
040D19E0	40 Fixed
040D1A20	30 Fixed
040D1A50	80 Fixed
040D1AD0	80 Fixed
040D1B50	40 Fixed
040D1B90	30 Fixed
040D1BC0	80 Fixed
040D1C40	80 Fixed
040D1CC0	40 Fixed
040D1D00	30 Fixed
040D1D30	80 Fixed
040D1DB0	80 Fixed
040D1E30	40 Fixed
040D1E70	30 Fixed
040D1EA0	80 Fixed
040D1F20	80 Fixed
040D1FA0	40 Fixed
040D1FE0	30 Fixed
040D2010	80 Fixed
040D2090	80 Fixed
040D2110	40 Fixed
040D2150	30 Fixed
040D2180	80 Fixed
040D2200	40 Fixed
040D2240	20 Fixed
040D2260	80 Fixed
040D22E0	80 Fixed
040D2360	40 Fixed
040D23A0	20 Fixed
040D23C0	80 Fixed
040D2440	80 Fixed
040D24C0	40 Fixed
040D2500	30 Fixed
040D2530	80 Fixed
040D25B0	80 Fixed
040D2630	40 Fixed
040D2670	30 Fixed
040D26A0	80 Fixed
040D2720	80 Fixed
040D27A0	40 Fixed
040D27E0	30 Fixed
040D2810	80 Fixed
040D2890	80 Fixed
040D2910	40 Fixed
040D2950	30 Fixed
040D2980	80 Fixed
040D2A00	80 Fixed
040D2A80	40 Fixed
040D2AC0	40 Fixed
040D2B00	80 Fixed
040D2B80	80 Fixed
040D2C00	B0 Fixed
040D2CB0	30 Fixed

040D2CE0	20 Fixed	040D3EB0	20 Fixed
040D2D00	40 Fixed	040D3ED0	40 Fixed
040D2D40	20 Fixed	040D3F10	20 Fixed
040D2D60	780 Fixed	040D3F30	40 Fixed
040D34E0	20 Fixed	040D3F70	20 Fixed
040D3500	20 Fixed	040D3F90	40 Fixed
040D3520	20 Fixed	040D3FD0	30 Fixed
040D3540	10 Free	040D4000	40 Fixed
040D3550	30 Fixed	040D4040	30 Fixed
040D3580	30 Fixed	040D4070	40 Fixed
040D35B0	20 Fixed	040D40B0	20 Fixed
040D35D0	30 Fixed	040D40D0	40 Fixed
040D3600	30 Fixed	040D4110	20 Fixed
040D3630	30 Fixed	040D4130	40 Fixed
040D3660	30 Fixed	040D4170	30 Fixed
040D3690	30 Fixed	040D41A0	40 Fixed
040D36C0	30 Fixed	040D41E0	20 Fixed
040D36F0	30 Fixed	040D4200	40 Fixed
040D3720	30 Fixed	040D4240	30 Fixed
040D3750	30 Fixed	040D4270	40 Fixed
040D3780	30 Fixed	040D42B0	20 Fixed
040D37B0	30 Fixed	040D42D0	40 Fixed
040D37E0	30 Fixed	040D4310	30 Fixed
040D3810	30 Fixed	040D4340	40 Fixed
040D3840	30 Fixed	040D4380	20 Fixed
040D3870	10 Free	040D43A0	40 Fixed
040D3880	40 Fixed	040D43E0	20 Fixed
040D38C0	40 Fixed	040D4400	40 Fixed
040D3900	20 Fixed	040D4440	20 Fixed
040D3920	40 Fixed	040D4460	40 Fixed
040D3960	20 Fixed	040D44A0	20 Fixed
040D3980	40 Fixed	040D44C0	40 Fixed
040D39C0	30 Fixed	040D4500	20 Fixed
040D39F0	40 Fixed	040D4520	40 Fixed
040D3A30	20 Fixed	040D4560	30 Fixed
040D3A50	40 Fixed	040D4590	40 Fixed
040D3A90	30 Fixed	040D45D0	30 Fixed
040D3AC0	40 Fixed	040D4600	40 Fixed
040D3B00	20 Fixed	040D4640	20 Fixed
040D3B20	40 Fixed	040D4660	40 Fixed
040D3B60	30 Fixed	040D46A0	30 Fixed
040D3B90	40 Fixed	040D46D0	40 Fixed
040D3BD0	30 Fixed	040D4710	20 Fixed
040D3C00	40 Fixed	040D4730	40 Fixed
040D3C40	20 Fixed	040D4770	30 Fixed
040D3C60	40 Fixed	040D47A0	40 Fixed
040D3CA0	20 Fixed	040D47E0	20 Fixed
040D3CC0	40 Fixed	040D4800	40 Fixed
040D3D00	20 Fixed	040D4840	20 Fixed
040D3D20	40 Fixed	040D4860	40 Fixed
040D3D60	30 Fixed	040D48A0	20 Fixed
040D3D90	40 Fixed	040D48C0	40 Fixed
040D3DD0	30 Fixed	040D4900	20 Fixed
040D3E00	40 Fixed	040D4920	40 Fixed
040D3E40	30 Fixed	040D4960	20 Fixed
040D3E70	40 Fixed	040D4980	40 Fixed

040D49C0	30 Fixed	040D55C0	30 Fixed
040D49F0	40 Fixed	040D55F0	40 Fixed
040D4A30	30 Fixed	040D5630	30 Fixed
040D4A60	40 Fixed	040D5660	40 Fixed
040D4AA0	30 Fixed	040D56A0	40 Fixed
040D4AD0	40 Fixed	040D56E0	40 Fixed
040D4B10	30 Fixed	040D5720	30 Fixed
040D4B40	40 Fixed	040D5750	40 Fixed
040D4B80	20 Fixed	040D5790	20 Fixed
040D4BA0	40 Fixed	040D57B0	40 Fixed
040D4BE0	30 Fixed	040D57F0	30 Fixed
040D4C10	40 Fixed	040D5820	40 Fixed
040D4C50	20 Fixed	040D5860	20 Fixed
040D4C70	40 Fixed	040D5880	40 Fixed
040D4CB0	30 Fixed	040D58C0	40 Fixed
040D4CE0	40 Fixed	040D5900	40 Fixed
040D4D20	30 Fixed	040D5940	40 Fixed
040D4D50	40 Fixed	040D5980	40 Fixed
040D4D90	30 Fixed	040D59C0	40 Fixed
040D4DC0	40 Fixed	040D5A00	40 Fixed
040D4E00	30 Fixed	040D5A40	30 Fixed
040D4E30	40 Fixed	040D5A70	40 Fixed
040D4E70	30 Fixed	040D5AB0	20 Fixed
040D4EA0	40 Fixed	040D5AD0	40 Fixed
040D4EE0	30 Fixed	040D5B10	30 Fixed
040D4F10	40 Fixed	040D5B40	40 Fixed
040D4F50	30 Fixed	040D5B80	20 Fixed
040D4F80	40 Fixed	040D5BA0	40 Fixed
040D4FC0	30 Fixed	040D5BE0	40 Fixed
040D4FF0	40 Fixed	040D5C20	40 Fixed
040D5030	20 Fixed	040D5C60	30 Fixed
040D5050	40 Fixed	040D5C90	40 Fixed
040D5090	30 Fixed	040D5CD0	30 Fixed
040D50C0	40 Fixed	040D5D00	40 Fixed
040D5100	20 Fixed	040D5D40	30 Fixed
040D5120	40 Fixed	040D5D70	40 Fixed
040D5160	30 Fixed	040D5DB0	30 Fixed
040D5190	40 Fixed	040D5DE0	40 Fixed
040D51D0	30 Fixed	040D5E20	30 Fixed
040D5200	40 Fixed	040D5E50	40 Fixed
040D5240	30 Fixed	040D5E90	20 Fixed
040D5270	40 Fixed	040D5EB0	40 Fixed
040D52B0	30 Fixed	040D5EF0	30 Fixed
040D52E0	40 Fixed	040D5F20	40 Fixed
040D5320	30 Fixed	040D5F60	30 Fixed
040D5350	40 Fixed	040D5F90	40 Fixed
040D5390	30 Fixed	040D5FD0	30 Fixed
040D53C0	40 Fixed	040D6000	40 Fixed
040D5400	30 Fixed	040D6040	30 Fixed
040D5430	40 Fixed	040D6070	40 Fixed
040D5470	30 Fixed	040D60B0	20 Fixed
040D54A0	40 Fixed	040D60D0	40 Fixed
040D54E0	30 Fixed	040D6110	20 Fixed
040D5510	40 Fixed	040D6130	720 Fixed
040D5550	30 Fixed	040D6850	250 Fixed
040D5580	40 Fixed	040D6AA0	20 Fixed

040D6AC0	30 Fixed	040DD1D0	10 Free
040D6AF0	30 Fixed	040DD1E0	20 Fixed
040D6B20	190 Free	040DD200	30 Fixed
040D6CB0	50 Fixed	040DD230	20 Free
040D6D00	F0 Fixed	040DD250	20 Fixed
040D6DF0	A0 Fixed	040DD270	20 Fixed
040D6E90	A0 Fixed	040DD290	20 Fixed
040D6F30	90 Fixed	040DD2B0	20 Fixed
040D6FC0	30 Fixed	040DD2D0	20 Fixed
040D6FF0	30 Fixed	040DD2F0	20 Fixed
040D7020	30 Fixed	040DD310	410 Fixed
040D7050	30 Fixed	040DD720	410 Fixed
040D7080	30 Fixed	040DDB30	410 Fixed
040D70B0	30 Fixed	040DDF40	410 Fixed
040D70E0	30 Fixed	040DE350	100 Fixed
040D7110	30 Fixed	040DE450	20 Fixed
040D7140	30 Fixed	040DE470	20 Fixed
040D7170	30 Fixed	040DE490	20 Fixed
040D71A0	30 Fixed	040DE4B0	20 Fixed
040D71D0	30 Fixed	040DE4D0	20 Fixed
040D7200	30 Fixed	040DE4F0	20 Fixed
040D7230	30 Fixed	040DE510	20 Fixed
040D7260	30 Fixed	040DE530	20 Fixed
040D7290	30 Fixed	040DE550	20 Fixed
040D72C0	30 Fixed	040DE570	20 Fixed
040D72F0	30 Fixed	040DE590	40 Free
040D7320	30 Fixed	040DE5D0	20 Fixed
040D7350	B0 Fixed	040DE5F0	20 Fixed
040D7400	30 Fixed	040DE610	10 Free
040D7430	40 Fixed	040DE620	20 Fixed
040D7470	50 Fixed	040DE640	30 Fixed
040D74C0	30 Free	040DE670	40 Free
040D74F0	210 Fixed	040DE6B0	20 Fixed
040D7700	40 Fixed	040DE6D0	20 Free
040D7740	20 Fixed	040DE6F0	20 Fixed
040D7760	210 Fixed	040DE710	20 Fixed
040D7970	B0 Fixed	040DE730	10 Free
040D7A20	40 Fixed	040DE740	20 Fixed
040D7A60	40 Fixed	040DE760	30 Fixed
040D7AA0	80 Free	040DE790	20 Fixed
040D7B20	30 Fixed	040DE7B0	20 Fixed
040D7B50	2D0 Fixed	040DE7D0	10 Free
040D7E20	120 Free	040DE7E0	20 Fixed
040D7F40	720 Fixed	040DE800	30 Fixed
040D8660	4A10 Fixed	040DE830	20 Fixed
040DD070	20 Fixed	040DE850	20 Fixed
040DD090	10 Free	040DE870	10 Free
040DD0A0	20 Fixed	040DE880	20 Fixed
040DD0C0	30 Fixed	040DE8A0	30 Fixed
040DD0F0	20 Fixed	040DE8D0	20 Fixed
040DD110	20 Fixed	040DE8F0	20 Fixed
040DD130	10 Free	040DE910	20 Fixed
040DD140	20 Fixed	040DE930	30 Fixed
040DD160	30 Fixed	040DE960	30 Fixed
040DD190	20 Fixed	040DE990	20 Fixed
040DD1B0	20 Fixed	040DE9B0	10 Free

040DE9C0	20 Fixed	040DF2A0	30 Fixed
040DE9E0	30 Fixed	040DF2D0	1C0 Free
040DEA10	20 Fixed	040DF490	20 Fixed
040DEA30	20 Fixed	040DF4B0	20 Fixed
040DEA50	20 Fixed	040DF4D0	10 Free
040DEA70	10 Free	040DF4E0	20 Fixed
040DEA80	20 Fixed	040DF500	30 Fixed
040DEAA0	30 Fixed	040DF530	20 Fixed
040DEAD0	20 Fixed	040DF550	20 Fixed
040DEAF0	20 Fixed	040DF570	10 Free
040DEB10	10 Free	040DF580	20 Fixed
040DEB20	20 Fixed	040DF5A0	10 Free
040DEB40	30 Fixed	040DF5B0	20 Fixed
040DEB70	20 Fixed	040DF5D0	20 Free
040DEB90	20 Fixed	040DF5F0	20 Fixed
040DEBB0	10 Free	040DF610	D0 Free
040DEBC0	20 Fixed	040DF6E0	20 Fixed
040DEBE0	30 Fixed	040DF700	60 Free
040DEC10	20 Fixed	040DF760	20 Fixed
040DEC30	20 Fixed	040DF780	20 Fixed
040DEC50	20 Fixed	040DF7A0	10 Free
040DEC70	30 Fixed	040DF7B0	20 Fixed
040DECA0	30 Fixed	040DF7D0	20 Fixed
040DECD0	20 Fixed	040DF7F0	20 Free
040DECF0	10 Free	040DF810	20 Fixed
040DED00	20 Fixed	040DF830	30 Fixed
040DED20	30 Fixed	040DF860	30 Fixed
040DED50	20 Fixed	040DF890	210 Fixed
040DED70	20 Fixed	040DFAA0	10 Free
040DED90	20 Fixed	040DFAB0	20 Fixed
040DEDB0	20 Fixed	040DFAD0	20 Fixed
040DEDD0	20 Fixed	040DFAF0	10 Free
040DEDF0	20 Free	040DFB00	20 Fixed
040DEE10	30 Fixed	040DFB20	30 Fixed
040DEE40	30 Fixed	040DFB50	20 Fixed
040DEE70	30 Fixed	040DFB70	20 Fixed
040DEEA0	30 Fixed	040DFB90	20 Free
040DEED0	20 Fixed	040DFBB0	30 Fixed
040DEEF0	1A0 Fixed	040DFBE0	20 Fixed
040DF090	20 Fixed	040DFC00	20 Fixed
040DF0B0	10 Free	040DFC20	10 Free
040DF0C0	20 Fixed	040DFC30	20 Fixed
040DF0E0	30 Fixed	040DFC50	30 Fixed
040DF110	20 Fixed	040DFC80	20 Fixed
040DF130	20 Fixed	040DFCA0	10 Free
040DF150	10 Free	040DFCB0	20 Fixed
040DF160	20 Fixed	040DFCD0	20 Fixed
040DF180	30 Fixed	040DFCF0	10 Free
040DF1B0	20 Fixed	040DFD00	20 Fixed
040DF1D0	10 Free	040DFD20	30 Fixed
040DF1E0	20 Fixed	040DFD50	110 Fixed
040DF200	30 Fixed	040DFE60	80 Fixed
040DF230	20 Fixed	040DFEE0	80 Fixed
040DF250	20 Fixed	040DFF60	20 Fixed
040DF270	10 Free	040DFF80	20 Fixed
040DF280	20 Fixed	040DFFA0	20 Fixed

040DFFC0	20 Free	040E0870	20 Fixed
040DFFE0	30 Fixed	040E0890	10 Free
040E0010	30 Fixed	040E08A0	20 Fixed
040E0040	20 Fixed	040E08C0	30 Fixed
040E0060	20 Fixed	040E08F0	20 Fixed
040E0080	10 Free	040E0910	20 Fixed
040E0090	20 Fixed	040E0930	20 Fixed
040E00B0	30 Fixed	040E0950	10 Free
040E00E0	20 Fixed	040E0960	20 Fixed
040E0100	20 Fixed	040E0980	30 Fixed
040E0120	10 Free	040E09B0	20 Fixed
040E0130	20 Fixed	040E09D0	20 Fixed
040E0150	30 Fixed	040E09F0	10 Free
040E0180	20 Fixed	040E0A00	20 Fixed
040E01A0	20 Fixed	040E0A20	30 Fixed
040E01C0	20 Free	040E0A50	20 Fixed
040E01E0	30 Fixed	040E0A70	20 Fixed
040E0210	30 Fixed	040E0A90	20 Free
040E0240	20 Fixed	040E0AB0	30 Fixed
040E0260	20 Free	040E0AE0	30 Fixed
040E0280	150 Fixed	040E0B10	20 Fixed
040E03D0	20 Fixed	040E0B30	20 Fixed
040E03F0	30 Fixed	040E0B50	10 Free
040E0420	30 Fixed	040E0B60	20 Fixed
040E0450	20 Fixed	040E0B80	30 Fixed
040E0470	20 Fixed	040E0BB0	20 Fixed
040E0490	10 Free	040E0BD0	20 Fixed
040E04A0	20 Fixed	040E0BF0	10 Free
040E04C0	30 Fixed	040E0C00	20 Fixed
040E04F0	20 Fixed	040E0C20	30 Fixed
040E0510	20 Fixed	040E0C50	20 Fixed
040E0530	10 Free	040E0C70	20 Fixed
040E0540	20 Fixed	040E0C90	10 Free
040E0560	30 Fixed	040E0CA0	20 Fixed
040E0590	20 Fixed	040E0CC0	30 Fixed
040E05B0	20 Fixed	040E0CF0	20 Fixed
040E05D0	10 Free	040E0D10	20 Fixed
040E05E0	20 Fixed	040E0D30	10 Free
040E0600	30 Fixed	040E0D40	20 Fixed
040E0630	20 Fixed	040E0D60	30 Fixed
040E0650	20 Fixed	040E0D90	340 Fixed
040E0670	20 Free	040E10D0	2A0 Fixed
040E0690	30 Fixed	040E1370	2A0 Fixed
040E06C0	30 Fixed	040E1610	2A0 Fixed
040E06F0	20 Free	040E18B0	2A0 Fixed
040E0710	20 Fixed	040E1B50	20 Fixed
040E0730	20 Fixed	040E1B70	20 Fixed
040E0750	10 Free	040E1B90	10 Free
040E0760	20 Fixed	040E1BA0	20 Fixed
040E0780	30 Fixed	040E1BC0	30 Fixed
040E07B0	20 Fixed	040E1BF0	20 Fixed
040E07D0	20 Fixed	040E1C10	20 Fixed
040E07F0	10 Free	040E1C30	20 Free
040E0800	20 Fixed	040E1C50	30 Fixed
040E0820	30 Fixed	040E1C80	30 Fixed
040E0850	20 Fixed	040E1CB0	20 Free

040E1CD0	20 Fixed	040E5960	30 Fixed
040E1CF0	20 Fixed	040E5990	140 Free
040E1D10	10 Free	040E5AD0	20 Fixed
040E1D20	20 Fixed	040E5AF0	20 Fixed
040E1D40	30 Fixed	040E5B10	30 Fixed
040E1D70	320 Fixed	040E5B40	10 Free
040E2090	260 Fixed	040E5B50	20 Fixed
040E22F0	260 Fixed	040E5B70	20 Fixed
040E2550	260 Fixed	040E5B90	10 Free
040E27B0	260 Fixed	040E5BA0	20 Fixed
040E2A10	260 Fixed	040E5BC0	30 Fixed
040E2C70	260 Fixed	040E5BF0	20 Fixed
040E2ED0	260 Fixed	040E5C10	20 Fixed
040E3130	260 Fixed	040E5C30	10 Free
040E3390	260 Fixed	040E5C40	20 Fixed
040E35F0	260 Fixed	040E5C60	30 Fixed
040E3850	260 Fixed	040E5C90	30 Fixed
040E3AB0	260 Fixed	040E5CC0	20 Fixed
040E3D10	260 Fixed	040E5CE0	20 Fixed
040E3F70	260 Fixed	040E5D00	20 Free
040E41D0	260 Fixed	040E5D20	30 Fixed
040E4430	260 Fixed	040E5D50	20 Fixed
040E4690	2C0 Fixed	040E5D70	20 Fixed
040E4950	230 Fixed	040E5D90	10 Free
040E4B80	230 Fixed	040E5DA0	20 Fixed
040E4DB0	230 Fixed	040E5DC0	30 Fixed
040E4FE0	230 Fixed	040E5DF0	20 Fixed
040E5210	1C0 Free	040E5E10	20 Fixed
040E53D0	20 Fixed	040E5E30	10 Free
040E53F0	20 Fixed	040E5E40	20 Fixed
040E5410	10 Free	040E5E60	30 Fixed
040E5420	20 Fixed	040E5E90	E0 Fixed
040E5440	30 Fixed	040E5F70	40 Fixed
040E5470	C0 Free	040E5FB0	40 Fixed
040E5530	20 Fixed	040E5FF0	40 Fixed
040E5550	20 Fixed	040E6030	40 Fixed
040E5570	10 Free	040E6070	50 Fixed
040E5580	20 Fixed	040E60C0	50 Fixed
040E55A0	30 Fixed	040E6110	30 Fixed
040E55D0	C0 Free	040E6140	20 Fixed
040E5690	20 Fixed	040E6160	20 Fixed
040E56B0	20 Fixed	040E6180	20 Free
040E56D0	20 Free	040E61A0	20 Fixed
040E56F0	30 Fixed	040E61C0	10 Free
040E5720	30 Fixed	040E61D0	20 Fixed
040E5750	20 Fixed	040E61F0	20 Fixed
040E5770	40 Free	040E6210	10 Free
040E57B0	20 Fixed	040E6220	20 Fixed
040E57D0	40 Free	040E6240	10 Free
040E5810	20 Fixed	040E6250	20 Fixed
040E5830	20 Fixed	040E6270	20 Fixed
040E5850	20 Free	040E6290	10 Free
040E5870	30 Fixed	040E62A0	20 Fixed
040E58A0	30 Fixed	040E62C0	30 Fixed
040E58D0	60 Free	040E62F0	30 Fixed
040E5930	30 Fixed	040E6320	20 Fixed

040E6340	20 Fixed	040E7100	30 Fixed
040E6360	20 Free	040E7130	20 Fixed
040E6380	20 Fixed	040E7150	20 Fixed
040E63A0	20 Fixed	040E7170	20 Free
040E63C0	20 Free	040E7190	30 Fixed
040E63E0	30 Fixed	040E71C0	30 Fixed
040E6410	30 Fixed	040E71F0	20 Fixed
040E6440	30 Fixed	040E7210	20 Fixed
040E6470	30 Fixed	040E7230	10 Free
040E64A0	20 Free	040E7240	20 Fixed
040E64C0	220 Fixed	040E7260	30 Fixed
040E66E0	30 Fixed	040E7290	20 Fixed
040E6710	20 Fixed	040E72B0	20 Fixed
040E6730	20 Fixed	040E72D0	20 Free
040E6750	10 Free	040E72F0	30 Fixed
040E6760	20 Fixed	040E7320	30 Fixed
040E6780	30 Fixed	040E7350	20 Fixed
040E67B0	20 Fixed	040E7370	10 Free
040E67D0	20 Fixed	040E7380	20 Fixed
040E67F0	10 Free	040E73A0	30 Fixed
040E6800	20 Fixed	040E73D0	20 Fixed
040E6820	30 Fixed	040E73F0	20 Fixed
040E6850	20 Fixed	040E7410	10 Free
040E6870	20 Fixed	040E7420	20 Fixed
040E6890	20 Free	040E7440	30 Fixed
040E68B0	30 Fixed	040E7470	20 Fixed
040E68E0	30 Fixed	040E7490	20 Fixed
040E6910	20 Fixed	040E74B0	10 Free
040E6930	20 Free	040E74C0	20 Fixed
040E6950	220 Fixed	040E74E0	30 Fixed
040E6B70	30 Fixed	040E7510	20 Fixed
040E6BA0	20 Fixed	040E7530	20 Fixed
040E6BC0	20 Free	040E7550	20 Free
040E6BE0	30 Fixed	040E7570	20 Fixed
040E6C10	30 Fixed	040E7590	20 Fixed
040E6C40	20 Fixed	040E75B0	20 Free
040E6C60	20 Fixed	040E75D0	30 Fixed
040E6C80	10 Free	040E7600	30 Fixed
040E6C90	20 Fixed	040E7630	20 Fixed
040E6CB0	30 Fixed	040E7650	10 Free
040E6CE0	20 Fixed	040E7660	20 Fixed
040E6D00	20 Fixed	040E7680	30 Fixed
040E6D20	10 Free	040E76B0	20 Fixed
040E6D30	20 Fixed	040E76D0	20 Fixed
040E6D50	30 Fixed	040E76F0	20 Free
040E6D80	20 Fixed	040E7710	30 Fixed
040E6DA0	20 Fixed	040E7740	30 Fixed
040E6DC0	20 Free	040E7770	20 Fixed
040E6DE0	220 Fixed	040E7790	20 Fixed
040E7000	30 Fixed	040E77B0	20 Free
040E7030	30 Fixed	040E77D0	30 Fixed
040E7060	30 Fixed	040E7800	30 Fixed
040E7090	20 Fixed	040E7830	20 Free
040E70B0	20 Fixed	040E7850	20 Fixed
040E70D0	10 Free	040E7870	20 Fixed
040E70E0	20 Fixed	040E7890	10 Free

040E78A0	20 Fixed	040E8190	30 Fixed
040E78C0	30 Fixed	040E81C0	20 Fixed
040E78F0	20 Fixed	040E81E0	20 Fixed
040E7910	20 Fixed	040E8200	10 Free
040E7930	10 Free	040E8210	20 Fixed
040E7940	20 Fixed	040E8230	30 Fixed
040E7960	30 Fixed	040E8260	100 Free
040E7990	20 Fixed	040E8360	220 Fixed
040E79B0	20 Fixed	040E8580	30 Fixed
040E79D0	20 Free	040E85B0	B0 Free
040E79F0	30 Fixed	040E8660	50 Fixed
040E7A20	30 Fixed	040E86B0	50 Fixed
040E7A50	20 Fixed	040E8700	A0 Free
040E7A70	20 Fixed	040E87A0	20 Fixed
040E7A90	10 Free	040E87C0	20 Fixed
040E7AA0	20 Fixed	040E87E0	10 Free
040E7AC0	30 Fixed	040E87F0	20 Fixed
040E7AF0	20 Fixed	040E8810	30 Fixed
040E7B10	20 Fixed	040E8840	50 Fixed
040E7B30	10 Free	040E8890	20 Free
040E7B40	20 Fixed	040E88B0	20 Fixed
040E7B60	30 Fixed	040E88D0	20 Fixed
040E7B90	30 Fixed	040E88F0	10 Free
040E7BC0	30 Fixed	040E8900	20 Fixed
040E7BF0	20 Fixed	040E8920	30 Fixed
040E7C10	20 Free	040E8950	20 Fixed
040E7C30	20 Fixed	040E8970	20 Fixed
040E7C50	20 Free	040E8990	20 Free
040E7C70	20 Fixed	040E89B0	30 Fixed
040E7C90	20 Fixed	040E89E0	30 Fixed
040E7CB0	10 Free	040E8A10	9E0 Fixed
040E7CC0	20 Fixed	040E93F0	20 Fixed
040E7CE0	30 Fixed	040E9410	60 Fixed
040E7D10	20 Fixed	040E9470	20 Free
040E7D30	20 Fixed	040E9490	20 Fixed
040E7D50	10 Free	040E94B0	20 Fixed
040E7D60	20 Fixed	040E94D0	10 Free
040E7D80	30 Fixed	040E94E0	20 Fixed
040E7DB0	20 Fixed	040E9500	30 Fixed
040E7DD0	20 Fixed	040E9530	20 Fixed
040E7DF0	20 Free	040E9550	20 Fixed
040E7E10	30 Fixed	040E9570	20 Free
040E7E40	30 Fixed	040E9590	30 Fixed
040E7E70	20 Fixed	040E95C0	30 Fixed
040E7E90	20 Fixed	040E95F0	20 Fixed
040E7EB0	10 Free	040E9610	20 Fixed
040E7EC0	20 Fixed	040E9630	20 Free
040E7EE0	30 Fixed	040E9650	30 Fixed
040E7F10	20 Fixed	040E9680	30 Fixed
040E7F30	20 Free	040E96B0	20 Fixed
040E7F50	30 Fixed	040E96D0	20 Fixed
040E7F80	1A0 Fixed	040E96F0	20 Free
040E8120	20 Fixed	040E9710	30 Fixed
040E8140	20 Fixed	040E9740	30 Fixed
040E8160	10 Free	040E9770	60 Free
040E8170	20 Fixed	040E97D0	20 Fixed

040E97F0	20 Fixed	040EAD90	140 Free
040E9810	20 Free	040EAED0	20 Fixed
040E9830	30 Fixed	040EAEF0	20 Fixed
040E9860	10 Free	040EAF10	10 Free
040E9870	20 Fixed	040EAF20	20 Fixed
040E9890	30 Fixed	040EAF40	30 Fixed
040E98C0	110 Free	040EAF70	20 Fixed
040E99D0	20 Fixed	040EAF90	20 Fixed
040E99F0	20 Fixed	040EAFB0	10 Free
040E9A10	20 Free	040EAFCD	20 Fixed
040E9A30	30 Fixed	040EAFE0	40 Free
040E9A60	30 Fixed	040EB020	20 Fixed
040E9A90	1B0 Free	040EB040	20 Fixed
040E9C40	20 Fixed	040EB060	20 Free
040E9C60	20 Fixed	040EB080	30 Fixed
040E9C80	10 Free	040EB0B0	30 Fixed
040E9C90	20 Fixed	040EB0E0	200 Free
040E9CB0	30 Fixed	040EB2E0	20 Fixed
040E9CE0	40 Free	040EB300	20 Fixed
040E9D20	20 Fixed	040EB320	80 Free
040E9D40	20 Fixed	040EB3A0	30 Fixed
040E9D60	20 Fixed	040EB3D0	30 Fixed
040E9D80	20 Fixed	040EB400	30 Fixed
040E9DA0	20 Fixed	040EB430	20 Fixed
040E9DC0	20 Fixed	040EB450	30 Fixed
040E9DE0	20 Fixed	040EB480	70 Fixed
040E9E00	20 Fixed	040EB4F0	30 Fixed
040E9E20	30 Fixed	040EB520	40 Fixed
040E9E50	20 Fixed	040EB560	20 Fixed
040E9E70	20 Fixed	040EB580	720 Fixed
040E9E90	10 Free	040EBCA0	20 Fixed
040E9EA0	20 Fixed	040EBCC0	20 Fixed
040E9EC0	30 Fixed	040EBCE0	40 Free
040E9EF0	20 Fixed	040EBD20	30 Fixed
040E9F10	20 Fixed	040EBD50	30 Fixed
040E9F30	20 Free	040EBD80	20 Fixed
040E9F50	30 Fixed	040EBDA0	100 Free
040E9F80	30 Fixed	040EBEA0	20 Fixed
040E9FB0	20 Fixed	040EBEC0	20 Fixed
040E9FD0	20 Fixed	040EBEE0	60 Free
040E9FF0	2C0 Fixed	040EBF40	30 Fixed
040EA2B0	230 Fixed	040EBF70	30 Fixed
040EA4E0	230 Fixed	040EBFA0	30 Fixed
040EA710	230 Fixed	040EBFD0	780 Fixed
040EA940	230 Fixed	040EC750	250 Fixed
040EAB70	E0 Free	040EC9A0	60 Free
040EAC50	20 Fixed	040ECA00	A0 Fixed
040EAC70	20 Fixed	040ECAA0	30 Fixed
040EAC90	10 Free	040ECAD0	120 Free
040EACA0	20 Fixed	040ECBF0	60 Fixed
040EACC0	30 Fixed	040ECC50	F0 Fixed
040EACF0	20 Fixed	040ECD40	A0 Fixed
040EAD10	20 Fixed	040ECDE0	A0 Fixed
040EAD30	10 Free	040ECE80	20 Fixed
040EAD40	20 Fixed	040ECEA0	20 Fixed
040EAD60	30 Fixed	040ECEC0	20 Fixed

040ECEE0	20 Fixed
040ECF00	1A0 Free
040ED0A0	30 Fixed
040ED0D0	A0 Free
040ED170	40 Fixed
040ED1B0	A0 Fixed
040ED250	20 Fixed
040ED270	130 Free
040ED3A0	A0 Fixed
040ED440	30 Fixed
040ED470	20 Fixed
040ED490	20 Fixed
040ED4B0	30 Fixed
040ED4E0	20 Free
040ED500	20 Fixed
040ED520	20 Fixed
040ED540	20 Free
040ED560	30 Fixed
040ED590	30 Fixed
040ED5C0	20 Fixed
040ED5E0	20 Fixed
040ED600	20 Free
040ED620	30 Fixed
040ED650	30 Fixed
040ED680	A0 Fixed
040ED720	200 Free
040ED920	A0 Fixed
040ED9C0	A0 Free
040EDA60	30 Free
040EDA90	40 Free
040EDAD0	180 Free
040EDC50	20 Fixed
040EDC70	20 Free
040EDC90	20 Fixed
040EDCB0	20 Fixed
040EDCD0	A0 Free
040EDD70	30 Free
040EDDA0	40 Free
040EDDE0	220 Free

Processes and their Modules
Module File Attributes Legend
RO - Read Only
H - Hidden
S - System
A - Archive
C - Compressed

NK.EXE base address: C2000000

=====

coredll.dll	01F60000	85000 RO, H, S, XIP
-------------	----------	---------------------

filesys.exe base address: 04000000

=====

coredll.dll	01F60000	85000 RO, H, S, XIP
oemregistry.dll	02670000	13000 RO, H, S, C, XIP
relfsd.dll	02700000	7000 RO, H, S, C, XIP
fatfsd.dll	02710000	11000 RO, H, S, C, XIP
binfs.dll	03FB0000	8000 RO, H, S, XIP
flashdrv.dll	03FC0000	8000 RO, H, S, XIP
msspart.dll	03FD0000	8000 RO, H, S, C, XIP
fsdmgr.dll	03FE0000	11000 RO, H, S, XIP

device.exe base address: 06000000

=====

rsaenh.dll	018B0000	1A000 RO, H, S, C, RAM
------------	----------	------------------------

from ROM

btceif.dll	018D0000	18000 RO, S, C, RAM
------------	----------	---------------------

from ROM

oemnotify.dll	019A0000	A000 RO, H, S, XIP
battdrv.dll	019B0000	9000 RO, H, S, XIP
frontlight.dll	019C0000	7000 RO, H, S, XIP
sdmemory.dll	019D0000	8000 RO, H, S, XIP
xscsdcard.dll	019E0000	8000 RO, H, S, XIP
sdbusdriver.dll	019F0000	D000 RO, H, S, XIP
coredll.dll	01F60000	85000 RO, H, S, XIP
ser2410.dll	021F0000	9000 RO, H, S, XIP
irsir.dll	02200000	7000 RO, H, S, XIP
pcmcia.dll	02210000	10000 RO, H, S, XIP
sc2410_usb_ser.dll	02220000	9000 RO, H, S, XIP
wavedev.dll	02230000	B000 RO, H, S, XIP
bthuniv.dll	024E0000	7000 RO, H, S, C, XIP
btd.dll	02520000	4C000 RO, H, S, C, XIP
crypt32.dll	02690000	42000 RO, H, S, C, XIP
ceddk.dll	026E0000	6000 RO, H, S, C, XIP
pm.dll	02730000	C000 RO, H, S, C, XIP
regenum.dll	02740000	5000 RO, H, S, C, XIP
wapdrv.dll	028B0000	1C000 RO, S, C, XIP
ossvcs.dll	028D0000	28000 RO, S, C, XIP
oleaut32.dll	02940000	30000 RO, H, S, C, XIP
ole32.dll	02970000	2F000 RO, H, S, C, XIP
btdrt.dll	029A0000	F000 RO, H, S, C, XIP
msasn1.dll	029B0000	E000 RO, H, S, C, XIP
ndisuio.dll	029C0000	8000 RO, H, S, C, XIP
ndis.dll	029D0000	23000 RO, H, S, C, XIP
afd.dll	02A00000	16000 RO, H, S, C, XIP
spnego.dll	02A20000	C000 RO, H, S, C, XIP
ircomm.dll	02A30000	6000 RO, H, S, C, XIP
pptp.dll	02A40000	11000 RO, H, S, C, XIP
ethman.dll	02A60000	6000 RO, H, S, C, XIP
audevman.dll	02A70000	A000 RO, H, S, C, XIP
msim.dll	02EE0000	33000 RO, S, C, XIP
msnsspc.dll	02F60000	9000 RO, S, C, XIP
shutil.dll	02F80000	8000 RO, H, S, C, XIP
aygshell.dll	02FD0000	23000 RO, H, S, C, XIP
commctrl.dll	03040000	5B000 RO, H, S, C, XIP
netui.dll	030A0000	1A000 RO, H, S, C, XIP
bthlink.dll	03150000	8000 RO, H, S, C, XIP

```

redir.dll 03200000 24000 RO, H, S, C, XIP
unimodem.dll 03230000 E000 RO, H, S, C, XIP
tapi.dll 03240000 13000 RO, H, S, C, XIP
irdastk.dll 03260000 13000 RO, H, S, C, XIP
gsm610.acm 03280000 C000 RO, H, S, C, XIP
waveapi.dll 03290000 1B000 RO, H, S, C, XIP
softkb.dll 032B0000 9000 RO, H, S, C, XIP
netbios.dll 03750000 C000 RO, H, S, C, XIP
tcpstk.dll 03760000 58000 RO, H, S, C, XIP
ip6hlp.dll 037C0000 B000 RO, H, S, C, XIP
tcpip6.dll 037D0000 54000 RO, H, S, C, XIP
dhcp.dll 03830000 A000 RO, H, S, C, XIP
eap.dll 03860000 8000 RO, H, S, C, XIP
eapol.dll 03870000 9000 RO, H, S, C, XIP
wzcsvc.dll 03890000 F000 RO, H, S, C, XIP
ntlmssp.dll 038A0000 D000 RO, H, S, C, XIP
schannel.dll 038B0000 1E000 RO, H, S, C, XIP
secur32.dll 038D0000 7000 RO, H, S, C, XIP
sslsp.dll 038E0000 A000 RO, H, S, C, XIP
nsp.dll 038F0000 6000 RO, H, S, C, XIP
wsp.dll 03900000 6000 RO, H, S, C, XIP
ws2inst.dll 03910000 5000 RO, H, S, C, XIP
ws2.dll 03920000 C000 RO, H, S, C, XIP
winsock.dll 03930000 5000 RO, H, S, C, XIP
iphlpapi.dll 03940000 10000 RO, H, S, C, XIP
cxport.dll 03950000 6000 RO, H, S, C, XIP
asynccm.dll 03960000 7000 RO, H, S, C, XIP
ppp.dll 03970000 1D000 RO, H, S, C, XIP
tshres.dll 7FFE0000 17000 RO, S, C, XIP

```

gwes.exe base address: 08000000

```

core.dll 01F60000 85000 RO, H, S, XIP
keybdr.dll 02630000 8000 RO, H, S, XIP
touch.dll 02640000 B000 RO, H, S, XIP
ddi.dll 02650000 1C000 RO, H, S, XIP
ossvc.dll 028D0000 28000 RO, S, C, XIP
oleaut32.dll 02940000 30000 RO, H, S, C, XIP
ole32.dll 02970000 2F000 RO, H, S, C, XIP
shutil.dll 02F80000 8000 RO, H, S, C, XIP
aygshell.dll 02FD0000 23000 RO, H, S, C, XIP
commctrl.dll 03040000 5B000 RO, H, S, C, XIP
tshres.dll 7FFE0000 17000 RO, S, C, XIP

```

connmgr.exe base address: 0A000000

```

core.dll 01F60000 85000 RO, H, S, XIP
configmanager.dll 02860000 10000 RO, S, C, XIP
ossvc.dll 028D0000 28000 RO, S, C, XIP
oleaut32.dll 02940000 30000 RO, H, S, C, XIP
ole32.dll 02970000 2F000 RO, H, S, C, XIP
cspnproxy.dll 03160000 8000 RO, S, C, XIP
cspnet.dll 03170000 9000 RO, S, C, XIP
cspas.dll 03180000 E000 RO, S, C, XIP

```

```

connplan.dll 03190000 A000 RO, S, C, XIP
cellcore.dll 031B0000 8000 RO, S, C, XIP
wininet.dll 03600000 78000 RO, H, S, C, XIP
shlwapi.dll 03690000 13000 RO, H, S, C, XIP
sslsp.dll 038E0000 A000 RO, H, S, C, XIP
wsp.dll 03900000 6000 RO, H, S, C, XIP
ws2.dll 03920000 C000 RO, H, S, C, XIP
iphlpapi.dll 03940000 10000 RO, H, S, C, XIP

```

shell32.exe base address: 0C000000

```

core.dll 01F60000 85000 RO, H, S, XIP
toolhelp.dll 026F0000 5000 RO, H, S, C, XIP
wap.dll 028A0000 6000 RO, S, C, XIP
ossvc.dll 028D0000 28000 RO, S, C, XIP
oleaut32.dll 02940000 30000 RO, H, S, C, XIP
ole32.dll 02970000 2F000 RO, H, S, C, XIP
btdrt.dll 029A0000 F000 RO, H, S, C, XIP
calstore.dll 02CF0000 1A000 RO, S, C, XIP
pimutil.dll 02E10000 28000 RO, S, C, XIP
chgtrk.dll 02E40000 A000 RO, S, C, XIP
outres.dll 02E60000 38000 RO, S, C, XIP
shutil.dll 02F80000 8000 RO, H, S, C, XIP
aygshell.dll 02FD0000 23000 RO, H, S, C, XIP
ceshell.dll 03000000 37000 RO, H, S, C, XIP
commctrl.dll 03040000 5B000 RO, H, S, C, XIP
cellcore.dll 031B0000 8000 RO, S, C, XIP
webview.dll 033F0000 B7000 RO, H, S, C, XIP
browser.dll 034B0000 2E000 RO, H, S, C, XIP
imaging.dll 035B0000 49000 RO, H, S, C, XIP
shlwapi.dll 03690000 13000 RO, H, S, C, XIP
sslsp.dll 038E0000 A000 RO, H, S, C, XIP
wsp.dll 03900000 6000 RO, H, S, C, XIP
ws2.dll 03920000 C000 RO, H, S, C, XIP
winsock.dll 03930000 5000 RO, H, S, C, XIP
iphlpapi.dll 03940000 10000 RO, H, S, C, XIP
pimapi.dll 03EA0000 7000 RO, S, C, XIP
tshres.dll 7FFE0000 17000 RO, S, C, XIP

```

services.exe base address: 0E000000

```

core.dll 01F60000 85000 RO, H, S, XIP
oleaut32.dll 02940000 30000 RO, H, S, C, XIP
ole32.dll 02970000 2F000 RO, H, S, C, XIP
btdrt.dll 029A0000 F000 RO, H, S, C, XIP
obexsrvr.dll 031C0000 A000 RO, H, S, C, XIP
sslsp.dll 038E0000 A000 RO, H, S, C, XIP
wsp.dll 03900000 6000 RO, H, S, C, XIP
ws2.dll 03920000 C000 RO, H, S, C, XIP
iphlpapi.dll 03940000 10000 RO, H, S, C, XIP

```

fexplore.exe base address: 10000000

```

coredll.dll 01F60000 85000 RO, H, S, XIP
ossvcs.dll 028D0000 28000 RO, S, C, XIP
oleaut32.dll 02940000 30000 RO, H, S, C, XIP
ole32.dll 02970000 2F000 RO, H, S, C, XIP
compime.dll 02ED0000 E000 RO, H, S, C, XIP
shutil.dll 02F80000 8000 RO, H, S, C, XIP
aygshell.dll 02FD0000 23000 RO, H, S, C, XIP
ceshell.dll 03000000 37000 RO, H, S, C, XIP
commctrl.dll 03040000 5B000 RO, H, S, C, XIP
cellcore.dll 031B0000 8000 RO, S, C, XIP
webview.dll 033F0000 B7000 RO, H, S, C, XIP
browser.dll 034B0000 2E000 RO, H, S, C, XIP
shlwapi.dll 03690000 13000 RO, H, S, C, XIP
ws2.dll 03920000 C000 RO, H, S, C, XIP
iphlpapi.dll 03940000 10000 RO, H, S, C, XIP
tshres.dll 7FFE0000 17000 RO, S, C, XIP

```

BTTrayCE.exe base address: 12000000

=====

```

btrez.dll 01800000 46000 RO, S, C, RAM from
ROM
btchooserlib.dll 01850000 27000 RO, S, C, RAM
from ROM
wbtapice.dll 01880000 C000 RO, S, C, RAM
from ROM
mfce300.dll 01C40000 6A000 RO, S, C, XIP
coredll.dll 01F60000 85000 RO, H, S, XIP
toolhelp.dll 026F0000 5000 RO, H, S, C, XIP
ossvcs.dll 028D0000 28000 RO, S, C, XIP
oleaut32.dll 02940000 30000 RO, H, S, C, XIP
ole32.dll 02970000 2F000 RO, H, S, C, XIP
doclist.dll 02C20000 C000 RO, S, C, XIP
note_prj.dll 02D40000 13000 RO, S, C, XIP

```

```

shutil.dll 02F80000 8000 RO, H, S, C, XIP
aygshell.dll 02FD0000 23000 RO, H, S, C, XIP
ceshell.dll 03000000 37000 RO, H, S, C, XIP
commctrl.dll 03040000 5B000 RO, H, S, C, XIP
tshres.dll 7FFE0000 17000 RO, S, C, XIP

```

poutlook.exe base address: 14000000

=====

```

coredll.dll 01F60000 85000 RO, H, S, XIP
ossvcs.dll 028D0000 28000 RO, S, C, XIP
oleaut32.dll 02940000 30000 RO, H, S, C, XIP
ole32.dll 02970000 2F000 RO, H, S, C, XIP
pimutil.dll 02E10000 28000 RO, S, C, XIP
outres.dll 02E60000 38000 RO, S, C, XIP
shutil.dll 02F80000 8000 RO, H, S, C, XIP
aygshell.dll 02FD0000 23000 RO, H, S, C, XIP
commctrl.dll 03040000 5B000 RO, H, S, C, XIP
tshres.dll 7FFE0000 17000 RO, S, C, XIP

```

DUMPMEM.EXE base address: 16000000

=====

```

coredll.dll 01F60000 85000 RO, H, S, XIP
toolhelp.dll 026F0000 5000 RO, H, S, C, XIP
ossvcs.dll 028D0000 28000 RO, S, C, XIP
oleaut32.dll 02940000 30000 RO, H, S, C, XIP
ole32.dll 02970000 2F000 RO, H, S, C, XIP
compime.dll 02ED0000 E000 RO, H, S, C, XIP
shutil.dll 02F80000 8000 RO, H, S, C, XIP
aygshell.dll 02FD0000 23000 RO, H, S, C, XIP
commctrl.dll 03040000 5B000 RO, H, S, C, XIP
tshres.dll 7FFE0000 17000 RO, S, C, XIP

```

Handheld Evidence Recovery Operator

Dr Kamal Jabbour, Sunderam Sankaran, Thomas N.J. Vestal
{jabbour, ssankara, tnvestal}@syr.edu
Syracuse University, Syracuse, NY

Abstract

Handheld devices present a class of computing platforms that provide its users mobility, connectivity, accessibility and organization. They also present a class of devices that are increasingly found during the course of legal investigations. Evidence acquisition tools for handheld devices are few, in contrast to the widespread use of these devices. There is a lack of clear understanding of the value of data contained in the devices and a standardized analysis process. In this paper, we discuss the general subject of forensic value of handheld devices by classifying the data they contain and data acquisition techniques. We introduce a prototype of an evidence acquisition tool, HERO, which uses Secure Digital storage cards for acquisition of data from Personal Digital Assistants running the Pocket PC operating system.

1. Introduction

A handheld device is characterized by an embedded operating system, a very small form factor, limited user input capability, limited storage, limited power and portability. The operating system (OS) is stored in a read only memory (ROM). Newer devices use flash drives for ROM to allow easy upgrades and updates to the OS. Some of the OS files are stored in a compressed format. The compressed files are loaded into main memory and decompressed before use. There also exist regions called Execute in Place (XIP). The files stored in these regions are capable of executing directly from ROM without loading into Random Access Memory (RAM). Handheld devices running the Pocket PC OS, for example, usually support XIP regions. The XIP regions allow OS modules to execute from the ROM thereby providing the user additional RAM for other applications. The RAM in mobile devices is unique since it serves as traditional memory for running applications and as storage for user data. This is in contrast to the PC where magnetic hard disk drives are used for storage. The amount of space allocated for storage and main memory is adjustable in many devices using a user interface. The file system used internally may not be apparent to a user. The user is presented with a unified view of the ROM, RAM and any other external storage. An example of this is the PIM information on a Pocket PC which is stored internally in the CE database format while the user views the data through an interface that hides the existence of the database. The user interface in handheld devices is very minimal and depends on the primary application of the device. A Personal Digital Assistant (PDA) has a more comprehensive interface than a cellular phone. Many of these devices have provisions for external storage cards. Handheld devices are powered by batteries and hence have limited power. The devices, operating system and applications are optimized for low power consumption. The characteristics of handheld devices discussed so far present a need for tools and techniques designed for these devices to conduct forensic investigations. The need is increasing as these

devices become more powerful, integrated and easy to use. Handheld devices provide a wealth of information and can be significant in a forensic investigation. We present a classification of data into common types found in handheld devices along with acquisition and analysis techniques for the data. The final section discusses the Handheld Evidence Recovery Operator (HERO) developed for the Pocket PC in detail.

2. Handheld Forensics

This paper deals with a set of digital sources collectively called handheld devices. Cell phones, personal digital assistants (PDA), smartphone, blackberries, smartwatches, Voice over Internet Protocol (VoIP) phones present a sampling of handheld devices found in the consumer market. The popular operating systems found on these devices are the Pocket PC (based on Windows CE), Palm OS, Symbian and sometimes Linux. Each of these devices has unique features and characteristics. They also have some commonalities.

2.1 Data Classification

Handheld devices could effectively provide the following classes of information.

- a. **Personal:** Information regarding personal contact information such as name, address and home telephone number is usually available on the device. This is valuable in investigations where the suspect who possesses the device is unwilling to talk or the device is found in a situation as part of a search. Information can be obtained from data such as contact lists which contain names, addresses and phone numbers of people, to-do lists that contain tasks to be completed, appointments, and notes taken at a meeting, voice memos, bank accounts and purchase orders. The information from the above data is valuable in understanding the suspect's past, current and future activities, and associations which may provide probable cause evidence to issue a comprehensive search warrant.
- b. **Archived:** Information that is present on the device but is not evident is classified as archived. This type of information is gathered from data stored in files and organized in directories. Files can contain images, audio, video, executables, contacts, notes, letters and more. The information from these sources could provide evidence against a suspect in a criminal proceeding or information that could lead to further investigation.
- c. **Residual:** This kind of information results from a number of activities, either by the user or the device. User activities include modification, deletion, creation and access. Some devices maintain logs of user activities. Creating or modifying data can result in the activity getting logged. This provides a means for non-repudiation in many cases. The log data could be modified to alter contents but such an act usually leaves the file modification date and time changed. The log file can be deleted. Most devices do not delete data when requested to do so, instead the entry for the file containing the data is removed from the allocation table and the space is marked as available for re-use. The device activities such as the last time a reboot was performed, new programs installed or uninstalled, location of the device where it was last used, the last user to log on to the

device, the files that were uploaded/downloaded to/from another device, last incoming/outgoing phone call, and the last access point that was discovered. This logged data is useful in narrowing the activities performed by the user of the device before it was discovered.

- d. Hidden: This type of information is found in slack spaces of storage drives and information hidden inside other files. The existence of this information is itself evidence of illegal activity in many cases. Image, audio and video files can contain data hidden inside using steganographic methods.
- e. Embedded: Data embedded in to the devices include PINs, manufacturer ID, network ID, make, model and serial number of the device. This information is helpful to obtain logs for the device from the network service provider and manuals from the manufacturer.

The data types described here are the target of data acquisition. All of the data types may not be present in a given device. Knowledge of device type and manufacturer documentation provides the investigator useful information before proceeding to the acquisition phase.

2.2 Data Acquisition Techniques

There are two classes of techniques for data acquisition from mobile devices. They are Physical and Peripheral. These are discussed here.

2.2.1 Physical: Situations where data is not recoverable using software, hardware devices are used for acquisition. Data stored on read only memory can be recovered using hardware interfaces that are built into the device. The manufacturer sometimes has interfaces for debugging and troubleshooting devices such as JTAG interfaces. These can be used to probe and read data that are otherwise inaccessible. Hardware readers for specific parts of the device also exist. This acquisition technique is not covered in this paper.

2.2.2 Peripheral: The case when the investigator has unrestricted access to the device, software tools can help acquire evidence. Handheld devices do not have removable primary storage. The OS in most cases resides in ROM and is constantly running. Traditional tools like boot disks cannot be used in this case. The OS then needs to participate in the acquisition process. The acquisition tool has several channels to get injected and executed on the device. Handheld devices have a data port for synchronization with a desktop computer. This feature is common to most devices in the market. The OS vendors usually have a remote API set for execution on the desktop. The remote API issues commands through the synchronization software to the device. The device runs a synchronization client that relays the commands to the OS and returns the results. Several tools utilize this for acquisition.

Another possibility is to use secondary storage for acquisition. SD card and CF card slots are common in many of the devices. The acquisition tool is stored in the card and invoked when the card is inserted into the device. The acquired data is stored on the card for further analysis. SD cards with 1 gigabyte capacity are available and are sufficient for devices available today.

3. Handheld Evidence Recovery Operator (HERO)

The Handheld Evidence Recovery Operator (HERO) developed at the Air Force Research Laboratory is a set of tools targeted at handheld devices with the ARM processor running Pocket PC operating system.

3.1 Pocket PC: The Pocket PC operating system is a derivative of Windows CE. Each version of the OS reflects a different version of the base Windows CE version. The popular versions are the Pocket PC 2002 phone edition and the Pocket PC 2003. The OS is run primarily on ARM core based processors such as the Intel XScale processor. The user interface is different from the Windows Desktop environment but gives a familiar set of system file names and icons. The user views the data in terms of files and folders similar to the Windows desktop. Internally the OS does not have the Current Folder or drive concept of the PC. Instead all folders are referenced relative to the root (“\”). For example, the folder C:\Windows\System on the PC is \Windows\System on the Pocket PC. The files in ROM and RAM are presented in a unified view and the user cannot differentiate between files in the ROM and those in RAM. Peripheral devices such as SD cards and CF cards are presented as folders in the root of the device. A SD card in a HP iPAQ with a 233 MHz Intel XScale processor running Pocket PC 2003, for example, will show as “Storage Card” in the root.

The Application Programming Interface (API) for the Pocket PC is a subset of the API for Windows on the PC. This gives traditional Windows programmers a smooth transition into the Pocket PC arena. From a forensic tool development standpoint, the API provides easy access to the data. The Pocket PC development environment provides a fairly complete set of Windows API, a C library and an MFC library as dynamic link libraries (DLL).

The Pocket PC also has a feature called the “Autorun” which allows the device to automatically execute a program stored on a peripheral storage card. The executable is stored in a specific folder with a specific name (autorun.exe for example) on the SD card. The name of the folder depends on the processor type. This feature is optional and may not be implemented on all devices.

The next section describes the set of tools developed for acquisition and analysis of data from Pocket PC based devices.

3.2 Acquisition: HERO has a set of five tools to acquire data from a given device. They reside on a SD card and execute in the main memory of the device. Most SD cards have a write lock which helps in preventing accidental writes to the card after the acquisition is complete. The executables are no more than 10 kilo bytes in size. The tools are capable of extracting the ROM, object store, databases, files and the registry.

The SD card is prepared with appropriate steps to sanitize the sectors. The card is formatted to support the FAT32 file system. The Pocket PC supports the FAT file system in addition to the Object Store.

The tools are stored on the SD card at a convenient location. Depending on the situation, the autorun feature can be used or the programs can be executed manually by using the user interface. Each tool determines the location and name of the SD card since the Pocket PC does not support the current directory feature. A progress bar indicates the state of the acquisition.

The files and directories on the device are copied as they are, maintaining relative positions, onto the SD card. The files copied include hidden files that may not be visible on the device. The tool that extracts the object store captures the files and directories in their compressed form. This does not include the files in ROM. The copy of the registry in RAM and the databases are present in the image. This is the bit image of the object store. The bit image is valuable when extracting deleted files and examining the free space. The database tool extracts the CE databases that store personal information. The extracted databases are stored in a CE database file. This file is in a format that is readable by another Pocket PC device with the same or similar characteristics as the original device. This is helpful when the device cannot be directly used for analysis.

The acquisition process can be automated by having an autorun program invoke each tool without user interruption. The autorun program can be set to execute when the SD card is inserted into the device. The advantage of using a SD card for acquisition is that it voids the need for equipment to be carried around. In addition, it serves the dual purpose of a field analysis tool for time-critical intelligence gathering.

3.3 Analysis: The evidence collected is stored on the SD card and the write lock is set. The analysis is done using a card reader and a PC with Windows XP Professional. The analysis software is installed on the PC. The installation is a self extracting executable that creates the appropriate folders, copies the files and creates registry keys. The program provides a graphical interface to navigate through the SD card. The program is aimed at assisting the investigator in the analysis process. There are several tools built in to help the analysis.

File Search: The file search utility searches for and lists files found based on the pattern specified. The pattern is a file name followed by its extension. The user can specify part of a file name to search for files with that pattern in the name. The option of searching in the current directory and sub-directories is available. The search function examines both the extension in the file name and the extension in the file header. The two are compared to determine if there is a discrepancy. Windows operating systems associate files with icons based on the extension in their name. This feature is helpful in finding files that are renamed to hide their original content. A separate list of files with extensions different from their headers is generated. Search filters such as date, time and size are available to narrow the search results. An indicator displays the progress of the search. The user can display the files in hex or ASCII format to examine the internals of the file. Image files are viewable in an image viewer in addition to the hex/ASCII display.

Keyword Search: The keyword search utility allows the user to search inside the files. The user specifies a keyword in hex or ASCII to search for within the files. This is sometimes helpful to understand the intended use of the file. For example, static strings within executables could reveal its purpose without the user having to execute the program.

Steganography detection: Steganography is the art of hiding information within messages. This utility allows the user to scan files for hidden information. The tools used are commonly available tools such as stegdetect. The utility allows the user to add new tools to the set.

Hash calculation: The user can calculate the MD5 hash of a string or file. This is useful to compare hash values of files to determine if they are modified. The MD5 implementation is derived from the RSA Data Security, Inc. MD5 Message-Digest Algorithm as specified in RFC 1321 by the IETF [2].

File recovery: The object store image obtained from the handheld device is a snapshot of the object store at the byte level. The Pocket PC OS does not completely delete a file. The OS assigns free blocks of storage as needed. This leaves fragments from previously deleted files inside the object store. The utility scans through the object store image for file headers and creates a file for each header found.

Logging: The user actions are logged to a file. The actions logged include log in time, searches performed, files opened, utilities used and logout time. The log is frequently written to disk. This is useful if the program is interrupted and has to be closed abruptly. The log maintains date and time of the actions along with the user that performed the actions.

The program does not allow the user to edit files and opens files in read only mode. A universal filtering scheme allows the user to display only files that are targeted. This is useful, for example, in cases where only image files are of interest. The program has a sign-in and sign-off scheme to log user activity.

3.4 Results

Preliminary tests conducted with the HERO have returned positive results. File integrity tests were conducted to determine if the tool modified the files on the device. The MD5 algorithm was used for file integrity checks. The MD5 hash of files was calculated on a device before running the tool. The hashes were stored on a PC for safe keeping. We ran the HERO tool on the device capturing the image and files. The MD5 hash of the files was gathered again and compared with the original set. The values matched and we concluded that the integrity of files was maintained by the tool. We performed the same test two more devices and the results were the same.

The object store image was used to recover deleted files. We placed a text file and an image file in the root folder of the device and ran the tool. A search for the file names revealed their existence in the object store image. We noted down the offset within the image where the files were found. We then deleted the files on the device using the user interface. We ran the tool again on the device. The object store image retained the files at the same offset even after deletion. We were able to recover the files by copying the bytes and pasting into a new file.

References

[1] “Steganography Detection with Stegdetect”, Neils Provos, URL:
<http://www.outguess.org/detection.php>

[2] “The MD5 Message-Digest Algorithm”, R. Rivest, MIT Laboratory for Computer Science and RSA Data Security, Inc., IETF Network Working Group RFC 1321, April 1992, URL:
<http://www.ietf.org/rfc/rfc1321.txt>